





ELITE

HIGH PERFORMANCE MACHINERY

Operating Instructions and Parts Manual

Horizontal Band Saw

Models EHB-916V | EHB-1018V



JET®

427 New Sanford Road
LaVergne, Tennessee 37086

www.jettools.com

Ph.: 855-336-4032

Part No. M-891050

Edition 10 03/2022

Copyright © 2022 JET



1.0 WARRANTY AND SERVICE

JET® warrants every product it sells against manufacturers' defects. If one of our tools needs service or repair, please contact Technical Service by calling 1-855-336-4032, 8AM to 5PM CST, Monday through Friday.

WARRANTY PERIOD

The general warranty lasts for the time period specified in the literature included with your product or on the official JET branded website, jettools.com.



WHO IS COVERED?

This warranty covers only the initial purchaser of the product from the date of delivery.

WHAT IS COVERED?

This warranty covers any defects in workmanship or materials subject to the limitations stated below. This warranty does not cover failures due directly or indirectly to misuse, abuse, negligence or accidents, normal wear-and-tear, improper repair, alterations or lack of maintenance.

HOW TO GET TECHNICAL SUPPORT

Please contact Technical Service by calling 1-855-336-4032. Please note that you will be asked to provide proof of initial purchase when calling. If a product requires further inspection, the Technical Service representative will explain and assist with any additional action needed. JET has Authorized Service Centers located throughout the United States. For the name of an Authorized Service Center in your area call 1-855-336-4032 or use the Service Center Locator on the JET website.

MORE INFORMATION

JET® is constantly adding new products. For complete, up-to-date product information, check with your local distributor or visit the JET website, jettools.com.

HOW STATE LAW APPLIES

This warranty gives you specific legal rights, subject to applicable state law.

LIMITATIONS ON THIS WARRANTY

JET LIMITS ALL IMPLIED WARRANTIES TO THE PERIOD OF THE LIMITED WARRANTY FOR EACH PRODUCT. EXCEPT AS STATED HEREIN, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE EXCLUDED. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

JET SHALL IN NO EVENT BE LIABLE FOR DEATH, INJURIES TO PERSONS OR PROPERTY, OR FOR INCIDENTAL, CONTINGENT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF OUR PRODUCTS. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

JET sells through distributors only. The specifications listed in JET printed materials and on official JET website are given as general information and are not binding. JET reserves the right to effect at any time, without prior notice, those alterations to parts, fittings, and accessory equipment which they may deem necessary for any reason whatsoever. JET® branded products are not sold in Canada by JPW Industries, Inc.

NOTE: JET is a division of JPW Industries, Inc. References in this document to JET also apply to JPW Industries, Inc., or any of its successors in interest to the JET brand.



2.0 TABLE OF CONTENTS

1.0 WARRANTY AND SERVICE	2
2.0 TABLE OF CONTENTS	4
3.0 SAFETY WARNINGS	5
4.0 INTRODUCTION	6
5.0 SPECIFICATIONS	6
6.0 UNCRATING AND ASSEMBLY	7
7.0 INSTALLATION	7
8.0 ELECTRICAL CONNECTIONS	7
9.0 CONTROLS	8
10.0 AUXILIARY COOLANT HOSE	8
11.0 PRIOR TO OPERATION	8
12.0 OPERATING CONTROLS AND ADJUSTMENTS	8
12.1 REMOVING AND INSTALLING THE BLADE	8
12.2 ADJUSTING BLADE GUIDE BRACKETS	9
12.3 ADJUSTING BLADE GUIDE ROLLER BEARINGS	10
12.4 CHANGING BLADE SPEED	10
12.5 OPERATING VISE	10
12.6 BOW WEIGHT ADJUSTMENT	11
12.7 ADJUSTING STOCK ADVANCE STOP	11
12.8 SETTING UP THE MACHINE FOR OPERATION	11
12.9 AUTOMATIC SHUT-OFF	12
12.10 GEAR CASE	12
12.11 ADJUST BLADE TENSION AND BLADE TRACKING ADJUSTMENT	12
13.0 MAINTENANCE	13
14.0 LUBRICATION	13
15.0 REPLACEMENT PARTS	13
16.0 WIRING DIAGRAM	34

3.0 SAFETY WARNINGS

1. Read and understand the entire owner's manual before attempting assembly or operation.
2. Read and understand the warnings posted on the machine and in this manual. Failure to comply with all of these warnings may cause serious injury.
3. Replace the warning labels if they become obscured or removed.
4. This band saw is designed and intended for use by properly trained and experienced personnel only. If you are not familiar with the proper and safe operation of a band saw, do not use until proper training and knowledge have been obtained.
5. Do not use this band saw for other than its intended use. If used for other purposes, JET®, disclaims any real or implied warranty and holds itself harmless from any injury that may result from that use.
6. Always wear approved safety glasses/face shields while using this band saw. Everyday eyeglasses only have impact resistant lenses; they are not safety glasses.
7. Before operating this band saw, remove tie, rings, watches and other jewelry, and roll sleeves up past the elbows. Remove all loose clothing and confine long hair. Non-slip footwear or anti-skid floor strips are recommended. Do not wear gloves.
8. Wear ear protectors (plugs or muffs) during extended periods of operation.
9. Do not operate this machine while tired or under the influence of drugs, alcohol or any medication.

10. Make certain the switch is in the OFF position before connecting the machine to the power supply.
11. Make certain the machine is properly grounded.
12. Make all machine adjustments or maintenance with the machine unplugged from the power source.
13. Remove adjusting keys and wrenches. Form a habit of checking to see that keys and adjusting wrenches are removed from the machine before turning it on.
14. Avoid contact with coolant, especially guarding your eyes.
15. Always keeps hands and fingers away from the blade when the machine is running.
16. Never hand hold the material. Always use the vise and clamp it securely.
17. Always provide adequate support for long and heavy material.
18. Keep safety guards in place at all times when the machine is in use. If removed for maintenance purposes, use extreme caution and replace the guards immediately after maintenance is complete.
19. Check damaged parts. Before further use of the machine, a guard or other part that is damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment of moving parts, binding of moving parts, breakage of parts, mounting and any other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced.
20. Do not use power tools in damp/wet locations or other dangerous environments. Do not expose them to rain. Keep work area well lighted. Provide for adequate space surrounding work area and non-glare overhead lighting.
21. Keep the floor around the machine clean and free of scrap material, oil and grease.
22. Keep visitors a safe distance from the work area. Keep children away. Workshop should be childproof; padlocks, master switches, remove starter keys.
23. Give your work undivided attention. Looking around, carrying on a conversation and "horse-play" are careless acts that can result in serious injury.
24. Maintain a balanced stance at all times so that you do not fall or lean against the blade or other moving parts. Do not overreach or use excessive force to perform any machine operation.
25. Use the right tool at the correct speed and feed rate. Do not force a tool or attachment to do a job for which it was not designed. The right tool will do the job better and more safely.
26. Use recommended accessories; improper accessories may be hazardous.
27. Maintain tools with care. Keep blade sharp and clean for the best and safest performance. Follow instructions for lubricating and changing accessories.
28. Maintain proper adjustment of blade tension, blade guides and thrust bearings.
29. Turn off the machine and disconnect from power before cleaning. Use a brush to remove chips or debris — do not use your hands.
30. Do not stand on the machine. Serious injury could occur if the machine tips over.
31. Never leave the machine running unattended. Turn the power off and do not leave the machine until it comes to a complete stop.
32. Be sure that the blade is not in contact with the workpiece when the motor is started. The motor shall be started and you should allow the saw to come up to full speed before bringing the saw blade into contact with the workpiece.
33. Adjust upper guide to clear workpiece. Hold workpiece firmly against table.
34. Direction of feed — feed work into a blade or cutter against the direction of rotation of the blade or cutter only.
35. Installation work and electrical wiring must be done by qualified electrician in accordance with all applicable codes and standards.
36. Do not remove jammed pieces until blade has stopped.

⚠ WARNING: This product can expose you to chemicals including lead and benzene which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to <http://www.p65warnings.ca.gov>.

⚠ WARNING: Some dust, fumes and gases created by power sanding, sawing, grinding, drilling, welding and other construction activities contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead based paint
- crystalline silica from bricks, cement and other masonry products
- arsenic and chromium from chemically treated lumber

Your risk of exposure varies, depending on how often you do this type of work. To reduce your exposure to these chemicals, work in a well-ventilated area and work with approved safety equipment, such as dust masks that are specifically designed to filter out microscopic particles. For more information go to <http://www.p65warnings.ca.gov/> and <http://www.p65warnings.ca.gov/wood>.



Familiarize yourself with the following safety notices used in this manual:

⚠ CAUTION

This means that if precautions are not heeded, it may result in minor injury and/or possible machine damage.

⚠ WARNING

This means that if precautions are not heeded, it may result in serious or even fatal injury.

4.0 INTRODUCTION

This manual is provided by JET® covering the safe operation and maintenance procedures for a JET Model EHB-916V and EHB-1018V. This manual contains instructions on installation, safety precautions, general operating procedures, maintenance instructions and parts breakdown. Your machine has been designed and constructed to provide years of trouble-free operation if used in accordance with the instructions as set forth in this document.

If there are questions or comments, please contact your local supplier or JET. JET can also be reached at our web site: www.jettools.com. Retain this manual for future reference. If the machine transfers ownership, the manual should accompany it.

5.0 SPECIFICATIONS

Model Number	EHB-916V	EHB-1018V
Stock Number	891050	891060
Capacity (in.):		
Round at 90°	9	10
Round at 45°	7	9
Rectangle at 90°	6 x 16	5 x 18
Rectangle at 45°	7 x 8 1/2	8 1/2 x 9
Vise Swivel	45°	45°
Blade Size (in.)	1 x 0.035 x 128	1 x 0.032 x 132 1/2
Blade Wheel Diameter (in.)	14	14
Blade Wheel Speed (SFPM)	53 - 257 Variable	53 - 257 Variable
Motor	1.5 HP, 115/230V, 1PH, 60 Hz, pre-wired 115V	2 HP, 230V, 1PH, 60Hz
Bed Height (in.)	27	27
Overall Dimensions (in.)	72 x 30 x 42	70 x 30 x 44
Net Weight - approx. (lbs.)	616	704
Shipping Weight - approx. (lbs.)	726	814

The specifications in this manual were current at time of publication, but because of our policy of continuous improvement, JET, reserves the right to change specifications at any time and without prior notice, without incurring obligations.

6.0 UNCRATING AND ASSEMBLY


Note: Read and understand the entire manual before attempting setup or operation.

1. Finish uncrating the saw and inspect for damage. Should any have occurred, contact your local distributor.
2. Remove all bolts attaching machine to shipping base.
3. Leave packing material between vise clamps and saw head intact until band saw has been lifted to its final position.
4. Clean all rust protected surfaces with kerosene or diesel oil to remove protective coating. Do not use gasoline, paint thinner, mineral spirits, etc. These may damage painted surfaces.
5. Lubricate all slideways with SAE 10W oil.

7.0 INSTALLATION

For best performance, the band saw should be located on a solid and level foundation. Allow room for servicing and for moving large stock around the band saw when deciding a location for the machine.

1. Using lifting straps that are isolated from the band saw's finished surfaces, lift machine and place in desired location. See Figure 1 for strap placement.
2. Install four leveling bolts with lock nuts on both sides of the base as shown in the parts breakdown on page 16, items 2 and 3.
3. Place a level on the table surface and check side-to-side and front-to-back.
4. Adjust leveling screws until machine is level in both directions and tighten locking nuts.



8.0 ELECTRICAL CONNECTIONS

⚠ WARNING

All electrical connections must be done by a qualified electrician. All adjustments or repairs must be done with machine disconnected from power source. Failure to comply may cause serious injury.

The EHB-916V Band Saw is rated at 115/230V single phase, and is pre-wired 115 volt from the factory. The EHB-1018V is rated at 230V only, single phase. Confirm that power available at the saw's location matches that for which the saw is wired.

To convert the EHB-916V from 115V to 230V, the following items will have to be changed:

Main Motor – follow diagram inside junction box cover.

Coolant Pump – Remove chip pan on front of saw, remove junction box cover on pump, and follow diagram inside junction box cover.

Control Transformer – Open electrical panel on rear of base and change the fuse from 115V to 230V.

Machine must always be correctly grounded.

NOTE: The power cord end will have to be changed to one rated 230V when changing to the higher voltage.

9.0 CONTROLS

Refer to Figure 2.

Power Indicator Light (A) – lit whenever machine is running.

WARNING

If the bulb is out, lamp will not light, but machine may still have power.

Start Button (B) – press to start band saw.

Emergency Stop Button (C) – press to immediately stop all machine functions.

Coolant Switch (D) – Turn arrow to “I” to turn on coolant flow. Turn arrow to “O” to stop coolant flow.

Feed Rate Control (E) – this knob is used to set the amount of downward force that is applied to the saw blade. The feed rate is proportional to the opening of the valve. When set to zero, the saw head is locked in the raised position. Increasing the valve opening (counterclockwise adjustment) increases the feed rate; decreasing the valve opening (clockwise adjustment) reduces the feed rate.




Fig. 2

10.0 AUXILIARY COOLANT HOSE

Your saw is equipped with an auxiliary coolant hose. This can be used when a large amount of coolant needs to be directed at the work piece.

11.0 PRIOR TO OPERATION

1. Check that blade tooth direction matches diagram on blade guides.
2. Check to see that blade is properly seated on wheels after applying correct tension (approximately 25,000 lbs.).
3. Set blade holder guides for approximately .003" to .005" clearance between guides and blade.
4. Check for slight clearance between back up rollers and back of blade.
5. Position blade guides as close to workpiece as possible.
6. Select proper speed and feed rate for material being cut.
7. Material to be cut must be securely held in vise.
8. Check to see that coolant level is adequate and turn on coolant pump if material to be cut requires it. Machine should be filled with four gallons of the proper coolant mixture. Follow the directions on the product maker's label and fill the coolant tank through the chip tray area.
9. Do not start cut on a sharp edge.
10. Keep machine lubricated. See “*Lubrication*” section.

12.0 OPERATING CONTROLS AND ADJUSTMENTS

12.1 REMOVING AND INSTALLING THE BLADE

When your machine was shipped, a blade was supplied and assembled to the saw.

1. Disconnect the machine from the power source.
2. Raise the saw frame about 6" and close the feed rate lever by turning it clockwise as far as it will go.
3. Open both wheel covers and clean the swarf out of the machine.
4. Release blade tension by turning the blade tension handwheel (C) Fig. 3 counterclockwise.
5. Remove the blade from both wheels and out of each blade guide.
6. Make sure the teeth of the new blade are pointing in the direction of travel. If necessary, turn the blade inside out.




Fig. 3




Fig. 4

7. Place the blade in place on the wheels (A) and through the upper blade guard (B) Fig. 3 is shown with the wheel covers removed for clarity.
8. Work the blade (F) all the way up into the blade guide roller bearings (D) with the back of the blade against the back-up bearing (E), as shown in Fig. 4.

NOTE: If roller bearings need adjusting refer to the section ADJUSTING BLADE GUIDE ROLLER BEARINGS.

9. Put light tension on the blade and work it on both wheels, as shown in Fig. 5.

MAKE SURE THAT THE BACK OF THE BLADE IS AGAINST THE WHEEL FLANGES OF BOTH WHEELS. THIS IS VERY IMPORTANT.

10. When you are sure the back of the blade is against the wheel flanges of both wheels and properly inserted into the guides, finish putting tension on the blade.

11. Jog the power "on" and "off" to be sure the blade is in place and tracking properly. If blade is not tracking properly refer to the section 12.11 "Adjust Blade Tension and Blade Tracking Adjustment".




Fig. 5

12.2 ADJUSTING BLADE GUIDE BRACKETS

The blade guides should be set as close to the vise jaw as possible. The right blade guide bracket (A) Fig. 6, is not adjustable and is set at the factory to clear the right hand vise jaw. The left blade guide bracket (B) can be moved to the left or right depending on the position of the left hand vise jaw (C).

To move the left blade guide bracket (B), loosen hand knob (D), position blade guide bracket (B) and tighten hand knob (D).

Note: when operating 916/SA, the right blade guide bracket (A) can be moved as well, especially when cutting in 90° to make sure the bracket be moved as close to the vise jaw as possible.




Fig. 6

12.3 ADJUSTING BLADE GUIDE ROLLER BEARINGS

The back of the blade (A) Fig. 7, should ride against the back-up support bearing (B) which is positioned at an angle so as to provide greater bearing support, eliminating bearing wear and extending blade life.

The saw blade (A) should also ride between the two roller bearings (C) and (D) Fig. 7.

The rear bearing (C) on the left hand blade guide can be easily adjusted to suit blade thickness by loosening nut (E). The bearing (C) is on an eccentric shaft which enables it to be adjusted for blade thickness in the same manner with the exception that the adjustable roller bearing is in the forward position.

Part (F) shown Fig. 8 is a tungsten carbide block, after completing the adjustments shown in Fig. 7, tighten the Part (F) onto the surface of the saw blade.




Fig. 7




Fig. 8

12.4 CHANGING BLADE SPEED

WARNING

Only adjust speed with power on and blade turning.

1. Raise cutting head approximately six inches above work piece and turn feed rate knob to zero.
2. Turn power on and turn speed adjuster knob (as in Figure 9) to match appropriate material.




Fig. 9

12.5 OPERATING VISE

The workpiece is placed between the vise jaws with the required amount to be cut-off extending out past the blade. To position the moveable vise jaw (B) instantly, simply turn vise handknob (A) Fig. 10, counterclockwise 1/2 turn and move the vise jaw (B) to the desired position. Then tighten vise by turning the knob (A) clockwise. The vise can be adjusted to cut any angle from 0° to 45° by loosening the two bolts (C) Fig. 10, on each vise jaw. Position the vise jaws to the desired angle and tighten the bolts. It is also necessary, when angle cutting, to move the right hand vise jaw (D) to the left until the workpiece and right hand vise jaw clears the right hand guide arm.




Fig. 10

12.6 BOW WEIGHT ADJUSTMENT

Bow weight is one of the most important adjustments of the saw. If the bow weight is not set properly, one can expect poor performance, crooked cuts, tooth stripping, stalling, and the blade popping off the blade wheels. The hydraulic feed rate unit will not compensate for improper bow weight. Bow weight has been set at the factory and should not need any adjustment. If adjustment becomes necessary:

1. Disconnect machine from power source.
2. Turn feed rate control (E, Figure 2) counterclockwise until it stops.
3. Place one end of a fish-type scale under the blade tension handle and lift the saw with the other end. The scale should indicate approximately 18-20 lbs. for the HBS-916W. For the HBS-1018W, it should indicate 22-24 lbs.
4. Adjust tension to approximately 18-20 lbs. (or 22-24 lbs.) by turning the adjustable C-bolt found at the end of the coil spring on the rear of the band saw.
5. Connect the machine to the power source.

12.7 ADJUSTING STOCK ADVANCE STOP

The Stock Advance Stop is used mainly when more than one piece is to be cut to the same length. Simply position the stop block (A) Fig. 11, the desired distance away from the blade.

The stop may be repositioned by loosening screw (B) and moving the rod (C) accordingly. To move the stop block (A) out of the way simply push it to the down position.




Fig. 11

12.8 SETTING UP THE MACHINE FOR OPERATION

1. Select the proper speed and blade for the type of material you are cutting.
2. Make sure blade tension is adjusted properly.
3. Lift the saw frame up and close the feed rate lever.
4. Place the stock between the vise jaws, set the stock for the desired width of cut and tighten the vise.
5. Make sure the left blade guide bracket (A) is adjusted as close as possible to the left vise jaw (B) Fig. 12.
6. Turn the machine on and if your machine is equipped with a coolant system, adjust coolant flow by turning lever (D) Fig. 2.
7. Turn the feed rate control (E) Fig 2, counterclockwise until the saw blade begins to lower the desired rate of speed.
8. Proceed to cut throughout the workpiece, as shown in Fig. 12. Shut the machine off upon completion of cut.




Fig. 12

12.9 AUTOMATIC SHUT-OFF

The machine and any accessories which are wired into the electrical system are controlled by the start-stop buttons. The machine will automatically shut off when the cut is completed. The lever (A) Fig. 13, for the automatic shut-off contacts the top of the hydraulic cylinder (B) and shuts off the machine.

LUBRICATION OF HYDRAULIC SYSTEM

If it is necessary to fill the hydraulic cylinder with oil, proceed as follows:

1. Lift the saw frame slightly (about 15°), place a block underneath the saw frame to hold it.
2. Turn cover (B) shown in Fig. 13 counterclockwise, then fill hydraulic oil or equivalent until it is full.




Fig. 13

12.10 GEAR CASE

After the first 50 hours of use the gear case should be drained and refilled. Remove drain plug (A) Fig. 14 drain all of the oil out of the gearbox. Remove oil filler plug located underneath the right wheel and fill the gear case with 850ml of multi-function gearbox oil or equivalent.




Fig. 14

12.11 ADJUST BLADE TENSION & BLADE TRACKING ADJUSTMENT

Blade tension has been preset in factory; therefore, by turning handwheel (A) in Fig. 15 clockwise until (B) portion slip then tension for the blade is reached. Please note that one does not need to press the handwheel, simply turn. For blade tracking, if the back of the blade is not against the wheel flange properly, loosen the screw (C) in Fig. 15, and adjust screw (D) in Fig. 15, until the blade is tracking properly, then tighten screw (C).




Fig. 15

13.0 MAINTENANCE

WARNING

Before doing maintenance on the machine, disconnect it from the electrical supply by pulling out the plug or switching off the main switch! Failure to comply may cause serious injury.

Keep the band saw and the motor clean.
If the power cord is worn, cut, or damaged in any way, have it replaced immediately.

14.0 LUBRICATION

All ball bearings are permanently lubricated and sealed. They require no further attention.

The gear box lubricant should be changed after the first 50 hours of operation. Change lubricant from then on every 250 hours of operation.

To check level of gear box lubricant, place saw arm in down position and allow a few minutes to pass so that oil drains down. Check level in sight glass on side of gear casing. Correct level is the dot in the middle of sight glass.

To change gear box lubricant:

1. Disconnect the machine from the power source.
2. Open drain plug and allow lubricant to drain completely. Drain plug may be found on lower front of gear case under right wheel cover. Remove drain plug with a hex wrench.
3. Replace drain plug.
4. Remove filler cap and fill gear box with Mobil DTE® Oil Heavy Medium until level reaches dot in middle of sight glass.
5. Replace filler cap.
6. Connect machine to the power source.

Use a light machine oil to lubricate all other moving parts as needed.

15.0 REPLACEMENT PARTS — EHB-916V and EHB-1018V

Replacement parts are listed on the following pages. To order parts or reach our service department, call 1-855-336-4032, Monday through Friday (see our website for business hours, www.jettools.com). Having the Model Number and Serial Number of your machine available when you call will allow us to serve you quickly and accurately.

JET®

427 New Sanford Road


LaVergne, Tennessee 37086

www.jettools.com

Phone: 855-336-4032



SAW STAND AND BED ASSEMBLY — EHB-916V



PARTS LIST SAW STAND AND BED — EHB-916V

Index No.	Part No.	Description	Size	Qty.
1	EHB916V-64	Fitting		1
2	EHB916V-65	Tubing	5/16" × 65"	2
3	EHB916V-66	Valve	.	1
4	EHB916V-67	Feed Knob	.	1
5	EHB916V-101	Cable Glands	PG-11	5
6	TS-0209071	Socket Head Cap Screw	3/8 × 1-1/2"	2
7	EHB916V-191	Special Washer		2
8	EHB916V-192	Vise Jaw Bracket		1
9	EHB916V-193	Roll Pin	3/16 × 1-1/8"	1
10	EHB916V-194	Bracket		1
11	EHB916V-195	Acme Nut Assembly		1
12	EHB916V-196	Button		1
13	EHB916V-197	Retainer		1
14	TS-0680011	Flat Washer	3/16"	2
15	EHB916V-199	Round Head Screw	3/16" x 3/8"	1
16	EHB916V-200	Block		1
17	EHB916V-201	Vise Jaw Bracket (fixed)		1
18	EHB916V-191	Special Washer		2
19	TS-0209061	Socket Head Cap Screw	3/8 × 1-1/4"	2
20	TS-0070031	Hex Cap Screw	1/2-13 × 1-1/2"	1
21	TS-0561031	Hex Nut	3/8"	1
22	EHB916V-206	Limit Switch		1
23	EHB916V-207	Limit Switch Seat(Ser No.13100009 and lower)		1
	EHB916V-207N	Limit Switch Seat(Ser No.xxxx0010 and higher)		1
	EHB916V-OHCA	Oil Hydraulic Cylinder Assembly (includes #24-34)		1
24	EHB916V-210	Cap		1
25	EHB916V-211	Oil Seal		1
26	EHB916V-213	Rod		1
27	TS-0680031	Flat Washer	5/16"	1
28	EHB916V-215	Piston		1
29	EHB916V-216	Seal		1
30	EHB916V-217	Inoin ring		1
31	TS-0561021	Hex Nut	5/16" x 18T	2
32	EHB916V-219	Tube Assembly		1
33	EHB916V-221	Tube fitting		1
34	EHB916V-222	Tube fitting		1
35	EHB916V-223	Retaining ring		1
36	EHB916V-224	Pivot shaft		1
37	EHB916V-225	Socket Set Screw	3/8"-16T × 3/8"	1
38	TS-0680031	Flat Washer	5/16"	4
39	TS-0051051	Hex Cap Screw	5/16 × 1"	4
40	EHB916V-232	Motor Plate		1
41	EHB916V-233	Rear Pivot Bracket		1
42	EHB916V-234	Special Socket Set Screw		2
43	EHB916V-235	Hex Nut	1/2"-12	2




Index No.	Part No.	Description	Size	Qty.
44	TS-0209081	Socket Head Cap Screw	3/8"-16T × 1-3/4"	3
45	TS-0680041	Flat Washer	3/8"	3
46	TS-0050031	Hex Cap Screw	1/4-20T × 3/4"	1
47	TS-0680021	Flat Washer	1/4"	1
48	TS-0271051	Set Screw	3/8"-16 × 1/2"	1
49	EHB916V-241	Strap		1
50	TS-0680021	Flat Washer	1/4"	2
51	EHB916V-243	Hex Cap Screw	1/4-20T × 3/4"	2
52	EHB916V-26	Special Washer		1
53	EHB916V-245	Knob		1
54	EHB916V-247	Bed		1
54-1	EHB916V-247-1	Seat		1
55	EHB916V-248	Pin		1
56	EHB916V-249	Hand Wheel		1
56-1	EHB916V-249-1	Handle		1
57	EHB916V-252	Acme Screw		1
57-1	EHB916V-252-1	Collar		1
58	EHB916V-253	Roll Pin	6 ø × 30 ø	1
59	EHB1018V-254	Work Support		1
60	TS-0680041	Flat Washer	3/8"	2
61	TS-0060061	Hex Cap Screw	3/8" × 1-1/4"	2
	EHB1018V-SA	Adj. Stock Stop Assembly (includes #62-66)		1
62	TS-0060061	Hex Cap Screw	3/8" × 1-1/4"	1
63	EHB1018V-258	Shaft	7/8"	1
64	EHB1018V-259	Stop Bracket		1
65	EHB1018V-260	Bar		1
66	EHB916V-261	Knob		2
67	EHB916V-265	Collar		2
68	TS-0271031	Set Screw	3/8-16T × 3/8"	4
69	EHB916V-267	Copper		2
70	TS-0271031	Socket Set Screw	3/8-16T × 3/8"	2
71	EHB916V-269	Pivot Shaft		1
72	EHB916V-272	Base Assembly		1
72-1	EHB916V-272-1	Door		1
72-2	EHB916V-272-2	Door		1
73	TS-0060031	Hex Cap Screw	3/8" × 3/4"	2
74	TS-0680041	Flat Washer	3/8"	2
75	EHB916V-275	Knob		1
76	EHB916V-276	Adjustable Bolt		1
77	EHB916V-277	Spring		1
78	EHB916V-278	Gun Set		1
78-1	EHB916V-278-1	Hook		1
78-2	EHB916V-278-2	Hex Cap Screw		2
79	EHB916V-281	Coolant Tank		1
79-1	EHB916V-281-1	Coolant Pump		1
79-2	EHB916V-281-2	Pan Head Machine Screw		4
79-3	EHB916V-96	3 Way Coolant Block		1

Index No.	Part No.	Description	Size	Qty.
79-4	EHB916V-281-4	Lock w/ key		1
79-5	EHB916V-281-5	Lock w/o key		1
80	EHB916V-283	Hex Nut	1/2"-12T	4
81	EHB916V-284	Hex Cap Screw	1/2" -12T x 2"	4
82	TS-0720081	Lock Washer	5/16"	3
83	TS-0051051	Hex Head Screw	5/16"-18 x 1"	3
84	EHB916V-289	Socket Head Button Screw	3/16" x 3/8"	8
85	EHB916V-300	Nameplate		1
86	EHB916V-301	Start Switch		1
87	EHB916V-302	Emergency Switch		1
88	EHB916V-303	Selection Switch		1
89	EHB916V-305	Indication Light For Power		1
90	EHB916V-306	Control Box		1
90-1	EHB916V-306-1	Tube		1



SAW ARM ASSEMBLY — EHB-916V



PARTS LIST SAW ARM — EHB-916V

Index No.	Part No.	Description	Size	Qty.
1	EHB916V-01	Handwheel		1
1-1	EHB916V-01-1	Handwheel handle		2
2	EHB916V-20	Lock Nut		1
3	EHB916V-03	Shaft		1
4	EHB916V-04	Bracket		1
5	EHB916V-05	Slide		1
6	EHB916V-06	Gib		2
7	EHB916V-07	Collar		1
8	EHB916V-08	Roll pin	M5x30	2
8-1	EHB916V-08-1	Roll pin	M5x40	1
9	TS-0081031	Hex Cap Screw	5/16 x 3/4	4
10	EHB916V-10	Adjusting Screw	3/4 x 1-1/2	1
11	TS-0060111	Hex Cap Screw	3/8 x 2-1/2	1
12	TS-0271031	Set Screw	3/8" x 3/8	1
13	EHB916V-13	Spindle		1
14	BB-51103	Thrust bearing	51103	2
15	TS-0060061	Hex Cap Screw	3/8 x 1-1/4	1
16	EHB916V-16	Roll pin	5 x 30L	1
17	TS-0732061	Lock Washer	3/8"	1
18	EHB916V-18	Driven		1
19	EHB916V-19	Thrust Bearing Housing		1
20	EHB916V-02	Collar		1
21	EHB916V-21	Disc Spring		6
22	EHB916V-22	Copper		1
23	TS-0267041	Set Screw	1/4 x 3/8	1
24	TS-0720081	Lock Washer	5/16"	1
25	TS-0060051	Hex Cap Screw	3/8" x 1"	1
26	EHB916V-26	Special Washer		1
28	EHB916V-28	Wheel L.H		1
29	BB6306ZZ	Bearing	6306ZZ	2
31	EHB916V-31	Output Shaft		1
32	EHB916V-32	Oil Seal	32.42.7.	1
33	BB-30207	Bearing		1
34	EHB916V-34	Oil Plug	1/4"	1
35	EHB916V-35	Gear Box housing	1	
35-1	EHB916V-35-1	Cover	1	
	EHB916V-GBCA	Gear Box Cover Assembly (includes 35, 35-1)	1	
36	TS-0060081	Hex Cap Screw	3/8-16 x 3/4"	3
37	TS-0732061	Lock Washer	3/8"	3
38	EHB916V-38	Worm Gear		1
39	EHB916V-39	Key	7 x 7 x 35	1
40	BB-30206	Bearing		1
41	TS-0267121	Set Screw	1/4" x 3/4"	3
42	EHB916V-42	Cap		1
43	TS-0732061	Lock Washer	3/8"	3
44	TS-0060071	Hex Cap Screw	3/8"-16 x 1-1/2"	3




Index No.	Part No.	Description	Size	Qty.
45	TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	3
46	TS-0561011	Hex Nut	1/4"	3
47	EHB916V-47	Cap		1
48	SB-3/16	Steel Ball		2
49	TS-0270061	Set Screw	5/16"-18 × 5/8"	1
50	TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	4
51	BB-6004	Bearing	6004	1
52	EHB916V-52	Input Shaft		1
55	BB-3205	Bearing	3205	1
56	EHB916V-56	Oil Seal	25.35.7	1
57	EHB916V-57	Cap		1
58	TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	4
68	EHB916V-68	Bow Frame		1
68-1	EHB916V-68-1	Frame Handle		1
70	TS-0081031	Hex Cap Screw	5/16" x 3/4"	2
71	TS-0680031	Flat Washer	5/16"	2
73	EHB916V-73	Tube Retainer		2
74	EHB916V-74	Round Head Screw	3/16" x 3/8"	2
75	EHB916V-75	Bracket (Left Side)		1
76	TS-0680031	Flat Washer	5/16"	2
77	TS-0081031	Hex Cap Screw	5/16" x 3/4"	2
78	TS-0081031	Hex Cap Screw	5/16" x 3/4"	2
79	TS-0680031	Flat Washer	5/16"	2
80	EHB916V-80	Drive Wheel.		1
81	TS-0271032	Socket Set Screw	3/8-24 × 3/8"	1
82	EHB916V-82	Key	7 × 7 × 40	1
83	TS-0081031	Hex Cap Screw	5/16-18 × 3/4"	2
84	TS-0720081	Lock Washer	5/16"	2
85	EHB916V-85	Bracket		1
86	EHB916V-86	Sensor		1
86-1	EHB916V-86-1	Sensor seat		1
86-2	EHB916V-86-2	Screw		2
87	EHB916V-87	Bracket		1
88	EHB916V-88	Knob		2
89	EHB916V-88	Knob		1
90	EHB916V-90	Blade Tension Gauge		1
	EHB916V-90A	Blade Tension Gauge Assembly (includes #20,90)		1
BTA	EHB916-BTA	Blade Tension Assembly (includes 1~24, 48~49, 90~90-1)		1
90-1	EHB916V-90-1	Pin		1
91	EHB916V-91	Front Pivot Bracket		1
92	TS-0732061	Lock Washer	3/8"	3
93	TS-0060081	Hex Cap Screw	3/8-16 × 3/4"	3
94	TS-0271051	Socket Set Screw	3/8-16 × 1/2"	1
95	EHB916V-95	Motor	1-1/2Hp, 115/230V	1
96	EHB916V-96	3 Way Coolant Block		1

Index No.	Part No.	Description	Size	Qty.
97	EHB916V-97	Hose		2
98	EHB916V-98	Valve		2
99	EHB916V-99	Hose Clamp		2
100	EHB916V-100	Belt		1
103	EHB916V-103	Upper Guard		1
109	EHB916V-109	Lower Guard		1
110	EHB916V-110	Motor Pulley		1
111	TS-0270021	Socket Set Screw	5/16-18 x 5/16"	1
112	EHB916V-112	Pulley		1
113	TS-0270021	Socket Set Screw	5/16-18 x 5/16"	1
114	EHB916V-114	Key	5 x 5 x 40	1
118	TS-0720081	Lock Washer	5/16"	2
119	EHB916V-119	Hex Head Screw	5/16"-20 x 3/4"	2
121	EHB916V-121	Round Head Screw	#10-3/16 x 3/8"	4
122	EHB916V-122	Cover R.H		1
123	TS-0255041	Socket Head Button Screw	5/16" x 18 x 3/4"	4
124	TS-0060051	Hex Cap Screw	3/8" x 16 x 1	1
125	TS-0561031	Hex Nut	3/8" x 16	1
126	TS-0680041	Lock Washer	3/8"	3
127	TS-0060081	Hex Cap Screw	3/8 x 16 x 3/4"	3
128	EHB916V-128	Stationary plate		2
129	EHB916V-129	Bracket		1
130	TS-0209071	Socket Head Cap Screw	3/8"-16 x 1-1/2"	2
131	TS-0267071	Set Screw	1/4"-20 x 3/4"	4
132	TS-0270061	Set Screw	5/16"-18 x 5/8"	1
133	EHB916V-133	Bracket-R.H.		1
134	EHB916V-134	Slide		1
134-1	EHB916V-134-1	Scale		1
135	EHB916V-135	Screw	3/16"-24 x 7/8"	4
136	EHB916V-136	Carbide Guide		4
137	EHB916V-137	Collar		2
138	TS-0267021	Set Screw	1/4"x1/4"	2
139	EHB916V-139	Wire Brush		1
140	EHB916V-140	Brush Support		1
141	TS-0207021	Socket Head Cap Screw	1/4"-20 x 5/8"	2
142	TS-0680021	Flat Washer	1/4" x 19 x 2.0	2
144	EHB916V-144	Guide, Right		1
144-1	EHB916V-144-1	Guide, Left		1
145	TS-0561021	Hex Nut	5/16"-18T	2
146	TS-0680041	Flat Washer	3/8"	4
147	BB6200ZZ	Bearing	6200 ZZ	1
148	EHB916V-148	Special Screw	M10 x 30	1
149	BB6200ZZ	Bearing	6200 ZZ	2
150	EHB916V-150	Special Screw		1
151	EHB916V-151	Special Screw		1
153	EHB916V-153	Adjustable Handle		1
154	EHB916V-154	Guide Cover		1
154-1	EHB916V-154-1	Screw	3/16" x 3/8"	2
154-2	TS-0680011	Washer		2



Index No.	Part No.	Description	Size	Qty.
155	EHB916V-155	Bracket-L.H.		1
156	EHB916V-156	Blade Cover		1
156-1	EHB916V-156-1	Screw		2
156-2	TS-0680011	Washer		2
157	EHB916V-157	Blade Cover		1
158	EHB916V-158	Special Knob		1
159	TS-0680041	Flat Washer	3/8"	3
160	EHB916V-160	Hex Head Screw	3/8 × 16 × 3/4"	3
161	EHB916V-161	Bracket		1
165	EHB916V-165	Round Head Screw	3/16 × 3/8"	4
166	EHB916V-166	Cover L.H		1
167	EHB916V-167	Handle		2
168	TS-081F051	Phillips Screw	1/4"-20 × 3/4"	4
169	891095	Blade	1"x 0.035" x 128-1/2" (4/6T)	1

SAW STAND AND BED ASSEMBLY — EHB-1018V





SAW STAND AND BED — EHB-1018V


Index No.	Part No.	Description	Size	Qty.
1	EHB916V-64	Fitting		2
2	EHB916V-65	Tubing	5/16" × 65".	2
3	EHB916V-66	Valve		1
4	EHB916V-67	Feed Knob		1
5	EHB916V-101	Cable Gland	PG-11	5
6	TS-0209071	Socket Head Cap Screw	3/8 × 1-1/2"	2
7	EHB916V-191	Special Washer		2
8	EHB1018V-192	Vise Jaw Bracket		1
9	EHB916V-193	Roll Pin	M5 x 20	1
10	EHB916V-194	Bracket		1
11	EHB916V-195	Acme Nut Assembly		1
12	EHB916V-196	Button		1
13	EHB916V-197	Retainer		1
14	TS-0680011	Flat Washer	3/16"	2
15	EHB916V-199	Round Head Screw	3/16" x 3/8"	1
16	EHB916V-200	Block		1
17	EHB1018V-201	Vise Jaw Bracket (fixed)		1
18	EHB916V-191	Special Washer		2
19	TS-0209061	Socket Head Cap Screw	3/8 × 1-1/4"	2
20	TS-0070031	Hex Cap Screw	1/2-13 × 1-1/2"	1
21	TS-0561031	Hex Nut	3/8"	1
22	EHB916V-206	Limit Switch		1
23	EHB916V-207	Limit Switch Seat(Ser No.13100009 and lower)		1
	EHB916V-207N	Limit Switch Seat (Ser No.xxxx0010 and higher)		1
	EHB1018V-OHCA	Oil Hydraulic Cylinder Assembly (includes # 24-34)		1
24	EHB916V-210	Cap		1
25	EHB916V-211	Oil Seal	20.35.7	1
26	EHB916V-213	Rod		1
27	TS-0680031	Flat Washer	5/16"	1
28	EHB916V-215	Piston		1
29	EHB916V-216	Seal		1
30	EHB916V-217	Inoin ring	P53	1
31	TS-0561021	Hex Nut	5/16" x 18T	2
32	EHB1018V-219	Tube Assembly		1
33	EHB916V-221	Tube Fitting		1
34	EHB916V-222	Tube Fitting		1
35	EHB916V-223	Retaining Ring	S-17	1
36	EHB916V-224	Pivot shaft		1
37	EHB916V-225	Socket Set Screw	3/8"-16T × 3/8"	1
38	TS-0680031	Flat Washer	5/16"	4
39	TS-0051051	Hex Cap Screw	5/16 × 1"	4
40	EHB916V-232	Motor Plate		1
41	EHB1018V-233	Rear Pivot Bracket		1
42	EHB916V-234	Special Socket Set Screw	1/2" x 2"	2

Index No.	Part No.	Description	Size	Qty.
43	EHB916V-235	Hex Nut	1/2"-12	2
44	TS-0209081	Socket Head Cap Screw	3/8"-16T × 1-3/4"	3
45	TS-0680041	Flat Washer	3/8"	3
46	TS-0050031	Hex Cap Screw	1/4-20T × 3/4"	1
47	TS-0680021	Flat Washer	1/4"	1
48	TS-0271051	Set Screw	3/8"-16 × 1/2"	1
49	EHB916V-241	Strap		1
50	TS-0680021	Flat Washer	1/4"	2
51	EHB916V-243	Hex Cap Screw	1/4-20T × 3/4"	2
52	EHB916V-26	Special Washer		1
53	EHB916V-245	Knob		1
54	EHB1018V-247	Bed		1
55	EHB916V-248	Pin		1
56	EHB916V-249	Hand Wheel		1
56-1	EHB916V-249-1	Handle		1
57	EHB1018V-252	Acme Screw		1
57-1	EHB916V-252-1	Collar		1
58	EHB916V-253	Roll Pin	6 ø × 30 ø	1
59	EHB1018V-254	Work Support		1
60	TS-0680041	Flat Washer	3/8"	2
61	TS-0060061	Hex Cap Screw	3/8" × 1-1/4"	2
	EHB1018V-SA	Adj. Stock Stop Assembly (includes #62-66)		1
62	TS-0060061	Hex Cap Screw	3/8" × 1-1/4"	1
63	EHB1018V-258	Shaft		1
64	EHB1018V-259	Stop Bracket		1
65	EHB1018V-260	Bar		1
66	EHB916V-261	Knob		2
67	EHB916V-265	Collar		2
68	TS-0271031	Socket Set Screw	3/8-16T × 3/8"	4
69	EHB916V-267	Copper		2
70	TS-0271031	Socket Set Screw	3/8-16T × 3/8"	2
71	EHB916V-269	Pivot Shaft		1
72	EHB1018V-272	Base Assembly		1
72-1	EHB916V-272-1	Door		1
72-2	EHB916V-272-2	Door		1
73	TS-0060031	Hex Cap Screw	3/8" × 3/4"	2
74	TS-0680041	Flat washer	3/8"	2
75	EHB-916V-275	Knob		1
76	EHB-916V-276	Adjustable Bolt		1
77	EHB916V-277	Spring		1
78	EHB916V-278	Gun Set		1
78-1	EHB916V-278-1	Hook		1
78-2	EHB916V-278-2	Hex Cap Screw		2
79	EHB916V-281	Coolant Tank		1
79-1	EHB1018V-281-1	Coolant Pump		1
79-2	EHB916V-281-2	Pan Head Machine Screw		4
79-3	EHB916V-96	3 Way Coolant Block		1



Index No.	Part No.	Description	Size	Qty.
79-4	EHB916V-281-4	Lock W/Key		1
79-5	EHB916V-281-5	Lock W/o Key		1
80	EHB916V-283	Hex Nut	1/2"-12T	4
81	EHB916V-284	Hex Cap Screw	1/2" -12T x 2"	4
82	EHB1018V-285	Seat		1
83	TS-0720081	Lockwasher	5/16"	3
84	TS-0051051	Hex Head Screw	5/16"-18 x 1"	3
85	EHB916V-289	Socket Head Button Screw	3/16" x 3/8"	8
86	EHB916V-300	Nameplate		1
87	EHB916V-301	Start Switch		1
88	EHB916V-302	Emergency Switch		1
89	EHB916V-303	Selection Switch		1
90	EHB916V-305	Indication Light For Power		1
91	EHB916V-306	Control Box		1
91-1	EHB916V-306-1	Tube		1

SAW ARM ASSEMBLY — EHB-1018V





PARTS LIST SAW ARM — EHB-1018V

Index No.	Part No.	Description	Size	Qty.
1	EHB916V-01	Handwheel		1
1-1	EHB916V-01-1	Handwheel handle		2
2	EHB916V-20	Lock Nut		1
3	EHB916V-03	Shaft		1
4	EHB916V-04	Bracket		1
5	EHB916V-05	Slide		1
6	EHB916V-06	Gib		2
7	EHB916V-07	Collar		1
8	EHB916V-08	Roll pin	M5x30	2
8-1	EHB916V-08-1	Roll pin	M5x40	1
9	TS-0081031	Hex Cap Screw	5/16 x 3/4	4
10	EHB916V-10	Adjusting Screw	3/4 x 1-1/2	1
11	TS-0060111	Hex Cap Screw	3/8 x 2-1/2	1
12	TS-0271031	Set Screw	3/8" x 3/8	1
13	EHB916V-13	Spindle		1
14	BB-51103	Thrust Bearing	#51103	2
15	TS-0060061	Hex Cap Screw	3/8 x 1-1/4	1
16	EHB916V-16	Roll pin	5 x 30L	1
17	TS-0732061	Lock Washer	3/8"	1
18	EHB916V-18	Driven		1
19	EHB916V-19	Thrust Bearing Housing		1
20	EHB916V-02	Collar		1
21	EHB916V-21	Disc Spring		6
22	EHB916V-22	Copper		1
23	TS-0267041	Set Screw	1/4 x 3/8	1
24	TS-0720081	Lock Washer	5/16"	1
25	TS-0060051	Hex Cap Screw	3/8" x 1"	1
26	EHB916V-26	Special Washer		1
28	EHB916V-28	Wheel L.H.		1
29	BB-6306ZZ	Bearing	6306ZZ	2
31	EHB916V-31	Output Shaft		1
32	EHB916V-32	Oil Seal	32.42.7	1
33	BB-30207	Bearing		1
34	EHB916V-34	Oil Plug	1/4"	1
35	EHB916V-35	Gear Box housing	1	
35-1	EHB916V-35-1	Cover	1	
	EHB916V-GBCA	Gear Box Cover Assembly (includes 35, 35-1)	1	
36	TS-0060081	Hex Cap Screw	3/8-16 x 3/4"	3
37	TS-0732061	Lock Washer	3/8"	3
38	EHB916V-38	Worm Gear		1
39	EHB916V-39	Key	7 x 7 x 35	1
40	BB-30206	Bearing		1
41	TS-0267121	Set Screw	1/4" x 3/4"	3
42	EHB916V-42	Cap		1
43	TS-0732061	Lock Washer	3/8"	3
44	TS-0060071	Hex Cap Screw	3/8"-16 x 1-1/2"	3

Index No.	Part No.	Description	Size	Qty.
45	TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	3
46	TS-0561011	Hex Nut	1/4"	3
47	EHB916V-47	Cap		1
48	SB-3/16	Steel Ball		2
49	TS-0270061	Set Screw	5/16"-18 × 5/8"	1
50	TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	4
51	BB-6004	Bearing	6004	1
52	EHB916V-52	Input Shaft		1
55	BB-3205	Bearing	3205	1
56	EHB916V-56	Oil Seal	25.35.7	1
57	EHB916V-57	Cap		1
58	TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	4
68	EHB1018V-68	Bow Frame		1
68-1	EHB916V-68-1	Frame Handle		1
70	TS-0081031	Hex Cap Screw	5/16" x 3/4"	2
71	TS-0680031	Flat Washer	5/16"	2
73	EHB916V-73	Tube Retainer		2
74	EHB916V-74	Round Head Screw	3/16" x 3/8"	2
75	EHB1018V-75	Bracket (Left Side)		1
76	TS-0680031	Flat Washer	5/16"	2
77	TS-0081031	Hex Cap Screw	5/16-18 × 3/4"	2
78	TS-0081031	Hex Cap Screw	5/16-18 × 3/4"	2
79	TS-0680031	Flat Washer	5/16"	2
80	EHB916V-80	Drive Wheel.		1
81	TS-0271032	Socket Set Screw	3/8-24 × 3/8"	1
82	EHB916V-82	Key	7 x 7 x 40	1
83	TS-0081031	Hex Cap Screw	5/16-18 × 3/4"	2
84	TS-0720081	Lock Washer	5/16"	2
85	EHB916V-85	Bracket		1
86	EHB916V-86	Sensor		1
86-1	EHB916V-86-1	Sensor seat		1
86-2	EHB916V-86-2	Screw		2
87	EHB1018V-87	Bracket		1
88	EHB916V-88	Knob		2
89	EHB916V-88	Knob		1
90	EHB916V-90	Blade Tension Gauge		1
	EHB916V-90A	Blade Tension Gauge Assembly (includes #20,90)		1
BTA	EHB916-BTA	Blade Tension Assembly (includes 1~24, 48~49, 90~90-1)		1
90-1	EHB916V-90-1	Pin		1
91	EHB1018V-91	Front Pivot Bracket		1
92	TS-0732061	Lock Washer	3/8"	3
93	TS-0060081	Hex Cap Screw	3/8-16 × 3/4"	3
94	TS-0271051	Socket Set Screw	3/8-16 × 1/2"	1
95	EHB1018V-95	Motor	2Hp,230V	1
96	EHB916V-96	3 Way Coolant Block		1




Index No.	Part No.	Description	Size	Qty.
97	EHB916V-97	Hose		2
98	EHB916V-98	Valve		2
99	EHB1018V-99	Hose Clamp		2
100	EHB916V-100	Belt		1
103	EHB916V-103	Upper Guard		1
109	EHB916V-109	Lower Guard		1
110	EHB916V-110	Motor Pulley		1
111	TS-0270021	Socket Set Screw	5/16-18 x 5/16"	1
112	EHB916V-112	Pulley		1
113	TS-0270021	Socket Set Screw	5/16-18 x 5/16"	1
114	EHB916V-114	Key	5 x 5 x 40	1
118	TS-0720081	Lock Washer	5/16"	2
119	EHB916V-119	Hex Head Screw	5/16"-20 x 3/4"	2
121	EHB916V-121	Round Head Screw	#10-3/16 x 3/8"	4
122	EHB916V-122	Cover R.H		1
123	TS-0680041	Lock Washer	3/8"	4
126	TS-0680041	Lock Washer	3/8"	3
127	TS-0060081	Hex Cap Screw	3/8"x16 x 3/4"	3
128	EHB1018V-128	Stationary plate		2
129	EHB1018V-129	Bracket		1
130	TS-0209061	Socket Head Cap Screw	3/8"-16 x 1-1/4"	2
131	TS-0267071	Set Screw	1/4"-20 x 3/4"	4
132	TS-0270061	Set Screw	5/16"-18 x 5/8"	1
133	EHB1018V-133	Bracket-R.H.		4
134	EHB1018V-134	Slide Way.		1
134-1	EHB916V-134-1	Scale		1
135	EHB916V-135	Screw	3/16"-24 x 7/8"	4
136	EHB916V-136	Carbide Guide		4
137	EHB1018V-137	Collar		2
138	TS-0267021	Set Screw	1/4"x1/4"	2
139	EHB916V-139	Wire Brush		1
140	EHB1018V-140	Brush Holder		1
141	TS-0207021	Socket Head Cap Screw	1/4"-20 x 5/8"	2
142	TS-0680021	Flat Washer	1/4" x 19 x 2.0	2
144	EHB916V-144	Guide, Right		1
144-1	EHB916V-144-1	Guide, Left		1
145	TS-0561021	Hex Nut	5/16"-18T	2
146	TS-0680041	Flat Washer	3/8"	4
147	BB-6200ZZ	Bearing	6200 ZZ	2
148	EHB916V-148	Special Screw	M10 x 30	1
149	BB-6200ZZ	Bearing	6200 ZZ	4
150	EHB916V-150	Special Screw		1
151	EHB916V-151	Special Screw		1
153	EHB916V-153	Adjustable Handle		1
154	EHB916V-154	Guide Cover		1
154-1	EHB916V-154-1	Screw	3/16" x 3/8"	2
154-2	TS-0680011	Washer		2
155	EHB1018V-155	Bracket-L.H.		4

Index No.	Part No.	Description	Size	Qty.
156	EHB916V-156	Blade Cover		1
156-1	EHB916V-156-1	Screw		2
156-2	TS-0680011	Washer		2
157	EHB916V-157	Blade Cover		1
158	EHB916V-158	Special Knob		2
159	TS-0680041	Flat Washer	3/8"	3
160	EHB1018V-160	Hex Head Screw	3/8"-16 x 3/4"	
161	EHB1018V-161	Bracket		1
165	EHB916V-165	Round Head Screw	3/16 x 3/8"	4
166	EHB-916V-166	Cover L.H		1
167	EHB916V-167	Handle		2
168	TS-081F051	Phillips Screw	1/4"-20 x 3/4"	4
169	891096	Blade	1" x 0.035" x 132-1/2" (4/6T)	1




ELECTRIC ASSEMBLY — EHB-916V



PARTS LIST ELECTRICAL BOX — EHB-916V

Index No.	Part No.	Description	Size	Qty.
308-1	EHB916V-308-1	Transformer	115/230/110V	1
308-2	EHB916V-308-2	Fuse Blocks	32A	1
308-2-1	EHB916V-308-2-1	Fuse	3A	1
308-3	EHB916V-308-3	Relay	100/110VAC	1
308-4	EHB916V-308-4	Relay Socket	CT-BMY2	1
308-5	EHB916V-308-5	Terminal Block		5
308-6	EHB916V-308-6	Electrical Plate		1
308-7	EHB916V-308-7	Round Head Screw	3/16" x 3/8"	30
308-8	TS-0680011	Washer	3/16"	30
308-9	EHB916V-308-9	Power Cable	(for 115V)	1
	EHB1018V-308-9	Power Cable	(for 230V)	1
308-10	EHB916V-308-10	Control Wire		1
308-11	EHB916V-308-11	Ground Cable	Yellow/Green	1
308-12	EHB916V-308-12	Overload Relay	15-20A (for 115V)	1
	EHB916V-308-12A	Overload Relay	7.2-10A(for 230V)	1
308-13	EHB916V-308-13	Magnetic Contactor	CU-11 110V	1
308-13-1	EHB916V-308-13-1	Magnetic Contactor	CU-16 110V	1
308-15	EHB916V-308-15	Motor Cable		1
308-16	EHB916V-308-16	Pump Cable		1
308-19	EHB916V-308-19	Limit Switch Cable		1

ELECTRIC ASSEMBLY — EHB-1018V




PARTS LIST ELECTRICAL BOX — EHB-1018V

Index No.	Part No.	Description	Size	Qty.
308-1	EHB916V-308-1	Transformer	115/230/110V	1
308-2	EHB916V-308-2	Fuse Blocks	32A	1
308-2-1	EHB916V-308-2-1	Fuse	3A	1
308-3	EHB916V-308-3	Relay	100/110VAC	1
308-4	EHB916V-308-4	Relay Socket	CT-BMY2	1
308-5	EHB916V-308-5	Terminal Block		5
308-6	EHB916V-308-6	Electrical Plate		1
308-7	EHB916V-308-7	Round Head Screw	3/16" x 3/8"	30
308-8	TS-0680011	Washer	3/16"	30
308-9	EHB1018V-308-9	Power Cable		1
308-10	EHB916V-308-10	Control Wire		1
308-11	EHB916V-308-11	Ground Cable	Yellow/Green	1
308-12	EHB1018V-308-12	Overload Relay	11.3-16A	1
308-13	EHB916V-308-13	Magnetic Contactor	CU-11 110V	1
308-13-1	EHB916V-308-13	Magnetic Contactor	CU-11 110V	1
308-15	EHB1018V-308-15	Motor Cable		1
308-16	EHB916V-308-16	Pump Cable		1
308-19	EHB916V-308-19	Limit Switch Cable		1



16.0 WIRING DIAGRAM



NOTES



NOTES