



Operating Instructions and Parts Manual

36-inch Metalworking Band Saw

Model VBS-3612



JET
427 New Sanford Road
La Vergne, Tennessee 37086
Ph.: 800-274-6848
www.jettools.com

Part No. M-414470A
Edition 10 08/2026
Copyright ©2026 JET

Warranty and Service

JET warrants every product it sells against manufacturers' defects. If one of our tools needs service or repair, please contact Technical Service by calling 1-800-274-6846, 8AM to 5PM CST, Monday through Friday.

Warranty Period

The general warranty lasts for the time period specified in the literature included with your product or on the official JET branded website.

- JET products carry a limited warranty which varies in duration based upon the product. (See chart below)
- Accessories carry a limited warranty of one year from the date of receipt.
- Consumable items are defined as expendable parts or accessories expected to become inoperable within a reasonable amount of use and are covered by a 90 day limited warranty against manufacturer's defects.

Who is Covered

This warranty covers only the initial purchaser of the product from the date of delivery.

What is Covered

This warranty covers any defects in workmanship or materials subject to the limitations stated below. This warranty does not cover failures due directly or indirectly to misuse, abuse, negligence or accidents, normal wear-and-tear, improper repair, alterations, or lack of maintenance. JET woodworking machinery is designed to be used with wood. Use of these machines in the processing of metal, plastics, or other materials outside recommended guidelines may void the warranty. The exceptions are acrylics and other natural items that are made specifically for wood turning.

Warranty Limitations

Woodworking products with a Five Year Warranty that are used for commercial or industrial purposes default to a Two Year Warranty. Please contact Technical Service at 1-800-274-6846 for further clarification.

How to Get Technical Support

Please contact Technical Service by calling 1-800-274-6846. **Please note that you will be asked to provide proof of initial purchase when calling.** If a product requires further inspection, the Technical Service representative will explain and assist with any additional action needed. JET has Authorized Service Centers located throughout the United States. For the name of an Authorized Service Center in your area call 1-800-274-6846 or use the Service Center Locator on the JET website.

More Information

JET is constantly adding new products. For complete, up-to-date product information, check with your local distributor or visit the JET website.

How State Law Applies

This warranty gives you specific legal rights, subject to applicable state law.

Limitations on This Warranty

JET LIMITS ALL IMPLIED WARRANTIES TO THE PERIOD OF THE LIMITED WARRANTY FOR EACH PRODUCT. EXCEPT AS STATED HEREIN, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE EXCLUDED. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

JET SHALL IN NO EVENT BE LIABLE FOR DEATH, INJURIES TO PERSONS OR PROPERTY, OR FOR INCIDENTAL, CONTINGENT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF OUR PRODUCTS. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

JET sells through distributors only. The specifications listed in JET printed materials and on official JET website are given as general information and are not binding. JET reserves the right to effect at any time, without prior notice, those alterations to parts, fittings, and accessory equipment which they may deem necessary for any reason whatsoever. JET® branded products are not sold in Canada by JPW Industries, Inc.

Product Listing with Warranty Period

90 Days – Parts; Consumable items
1 Year – Motors; Machine Accessories
2 Year – Metalworking Machinery; Electric Hoists, Electric Hoist Accessories; Woodworking Machinery used for industrial or commercial purposes
5 Year – Woodworking Machinery
Limited Lifetime – JET Parallel clamps; VOLT Series Electric Hoists; Manual Hoists; Manual Hoist Accessories; Shop Tools; Warehouse & Dock products; Hand Tools; Air Tools

NOTE: JET is a division of JPW Industries, Inc. References in this document to JET also apply to JPW Industries, Inc., or any of its successors in interest to the JET brand.

Table of Contents

Warranty and Service	2
Table of Contents	3
Warning	4
Introduction	6
Specifications	6
Features and Terminology	7
Unpacking	8
Contents of the Shipping Container	8
Installation and Assembly	9
Fence	9
Feed Screw	9
Shear	9
Circle Cutting Attachment	9
Grounding Instructions	9
Extension cords	10
230 Volt, Three-Phase Operation	10
Converting from 230 Volt to 460 Volt (Three Phase)	10
Three-Phase Test Run	10
Adjustments	11
Blade Removal and Installation	11
Blade Tension	11
Blade Tracking	11
Guide Post	12
Blade Guides	12
Squaring Work Table with Blade	13
Auxiliary Table	13
Replacing Drive Belts	13
Band Saw Operation	14
Blade Break-In Procedure	14
Setting Blade Speed	14
Evaluating Cutting Efficiency	14
Welder Operation	14
Shearing	14
Removing Teeth	15
Welding	15
Annealing	16
Blade Selection	17
Width	17
Gage	17
Pitch	17
Shape	18
Set	18
Material	18
Blade Breakage	19
Speed and Pitch Chart	21
Typical Band Saw Operations	22
Troubleshooting – Mechanical and Electrical Problems	24
Replacement Parts	27
Parts List: VBS-3612 Band Saw	28
Optional Accessories	32
VBS-3612 Band Saw	33
VBS-3612 Band Saw	34
Parts List: Welder, Shear and Work Lamp Assemblies	35
Welder, Shear and Work Lamp Assemblies	37
Electrical Connections – 3Ph, 230/460V	38
Electrical Connections – 3Ph, 230/460V	39
Electrical Box	40



Warnings

1. Read and understand the entire owner's manual before attempting assembly or operation.
2. Read and understand the warnings posted on the machine and in this manual. Failure to comply with all of these warnings may cause serious injury.
3. Replace the warning labels if they become obscured or removed.
4. This band saw is designed and intended for use only by properly trained and experienced personnel. If you are not familiar with the proper and safe operation of a band saw, do not use until proper training and knowledge have been obtained.
5. Do not use this band saw for other than its intended use. If used for other purposes, JET disclaims any real or implied warranty and holds itself harmless from any injury that may result from that use.
6. Always wear approved safety glasses/face shields while using this band saw. Everyday eyeglasses only have impact-resistant lenses; they are not safety glasses.
7. Before operating this band saw, remove tie, rings, watches, and other jewelry, and roll sleeves up past the elbows. Remove all loose clothing and confine long hair. Non-slip footwear or anti-skid floor strips are recommended. Do **not** wear gloves.
8. Wear ear protectors (plugs or muffs) during extended periods of operation.
9. Do not operate this machine while tired or under the influence of drugs, alcohol, or any medication.
10. Make certain the switch is in the **OFF** position before connecting the machine to the power supply.
11. Make certain the machine is properly grounded.
12. Make all machine adjustments or maintenance with the machine unplugged from the power source.
13. Remove adjusting keys and wrenches. Form a habit of checking to see that keys and adjusting wrenches are removed from the machine before turning it on.
14. Keep safety guards in place at all times when the machine is in use. If removed for maintenance purposes, use extreme caution and replace the guards immediately.
15. Check damaged parts. Before further use of the machine, any damaged guard or other part should be carefully checked to ensure it will operate properly and perform its intended function. Check for alignment and binding of moving parts, breakage of parts, proper mounting, and any other conditions that may affect its operation. Any damaged guard or other part should be properly repaired or replaced.
16. Provide adequate space surrounding the work area and non-glare, overhead lighting.
17. Keep the floor around the machine clean and free of scrap material, oil, and grease.
18. Keep visitors a safe distance from the work area. **Keep children away.**
19. Make your workshop child-proof with padlocks, master switches, or by removing starter keys.
20. Give your work undivided attention. Looking around, carrying on a conversation, and "horse-play" are careless acts that can result in serious injury.
21. Maintain a balanced stance at all times so that you do not fall or lean against the blade or other moving parts. Do not overreach or use excessive force to perform any machine operation.
22. Use the right tool at the correct speed and feed rate. Do not force a tool or attachment to do a job for which it was not designed. The right tool will do the job better and more safely.
23. Use recommended accessories; improper accessories may be hazardous.
24. Maintain tools with care. Keep blades sharp and clean for the best and safest performance. Follow instructions for lubricating and changing accessories.
25. Turn off the machine before cleaning. Use a brush or compressed air to remove chips or debris — do not use your hands.
26. Do not stand on the machine. Serious injury could occur if the machine tips over.

27. Never leave the machine running unattended. Turn the power off and do not leave the machine until the blade comes to a complete stop.
28. Remove loose items and unnecessary workpieces from the area before starting the machine.
29. Never place hands directly in line with the saw blade.
30. Always use push sticks when cutting small material.
31. Raise or lower the blade guide only when the machine has been turned off and the blade has stopped moving.
32. Always wear leather gloves when handling saw blades. The operator should not wear gloves when operating the machine.
33. Do not allow the saw blade to rest against the workpiece when the saw is not running.
34. The saw must be stopped, and the electrical supply must be cut off before any blade replacement, drive belt replacement, or any periodic service or maintenance is performed on the machine.
35. Remove cut-off pieces carefully, keeping hands away from the blade. The saw must be stopped, and the electrical supply cut off or the machine unplugged before reaching into the cutting area.

 **WARNING:** This product can expose you to chemicals including titanium dioxide which is known to the State of California to cause cancer, and lead which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to <http://www.p65warnings.ca.gov>.

 **WARNING:** Drilling, sawing, sanding or machining wood products generates wood dust and other substances known to the State of California to cause cancer. Avoid inhaling dust generated from wood products or use a dust mask or other safeguards for personal protection.

Wood products emit chemicals known to the State of California to cause birth defects or other reproductive harm. For more information, go to <http://www.p65warnings.ca.gov/wood>.

Familiarize yourself with the following safety notices used in this manual:

 CAUTION

This means that if precautions are not heeded, it may result in minor injury and/or possible machine damage.

 WARNING

This means that if precautions are not heeded, it may result in serious injury or possibly even death.

Introduction

This manual, provided by JET, covers the safe operation and maintenance procedures for the JET Model VBS-3612 Band Saw. This manual contains instructions on installation, safety precautions, general operating procedures, maintenance, and a parts breakdown. This machine has been designed and constructed to provide consistent, long-term operation if used in accordance with instructions set forth in this manual. If there are any questions or comments, please contact either your local supplier or JET. JET can also be reached at our website: www.jettools.com.

Retain this manual for future reference. If the machine transfers ownership, the manual should accompany it.

⚠ WARNING

Read and understand the entire contents of this manual before attempting assembly or operation. Failure to comply may cause serious injury.

Register your product using the mail-in card provided or register online: www.jettools.com/product-registration

To quickly reach the product registration webpage, scan the QR code below.







Specifications

Model Number	VBS-3612
Stock Number	414470
Blade Speeds (SFPM)	Low 50-410; High 540-4925
Height Capacity, Maximum (in.)	12
Throat Capacity, Maximum (in.)	36
Table Size, Main (L x W)(in.)	23-5/8 x 27-1/2
Table Size, Auxiliary (L x W)(in.)	17-3/4 x 27-1/2
Table Height at 90° (in.)	40
Table Tilt (deg.)	10° L, 45° R
Welder (KVA)	4.2
Blade Length, approx. (in.)	195-1/4 – 198-1/4
Blade Width (in.)	1/8 min., 1 max.
Motor	TEFC, 3HP, 3Ph, 230/460V (prewired 230V), 60Hz
Work Lamp Bulb	20W / 120V Halogen
Floor Space Required (LxWxH)(in.)	69 x 32 x 81
Net Weight (lbs.)	1,760

The above specifications were current at the time this manual was published, but because of our policy of continuous improvement, JET reserves the right to change specifications at any time and without prior notice, without incurring obligations.

Features and Terminology



- 1 – Main Work Table
- 2 – Work Lamp (20W/120V Bulb)
- 3 – Blade Tension Handwheel
- 4 – Auxiliary Work Table
- 5 – Variable Speed Handwheel
- 6 – Chip Port
- 7 – Gear Shift Lever
- 8 – Rod for Circle Cutting Attachment
- 9 – Guide Post Lock Knob
- 10 – Guide Post Raise/Lower Handwheel
- 11 – Blade Tracking Knob
- 12 – Electrical Box
- 13 – Blade Speed Readout (SFPM)
- 14 – Power Indicator Light

- 15 – Control Panel Lockout
- 16 – Emergency Stop Button
- 17 – Blade Start Button
- 18 – Blade Stop Button
- 19 – Shear
- 20 – Weld Switch
- 21 – Anneal Switch
- 22 – Clamp Pressure Selector
- 23 – Clamp Jaws
- 24 – Grinding Wheel Switch
- 25 – Grinding Wheel
- 26 – Clamp Handles
- 27 – Blade Tension Gauge
- 28 – Chip Blower Hose

Unpacking


Open the shipping container and check for shipping damage. Report any damage immediately to your distributor and shipping agent. Do not discard any shipping material until the Band Saw is set up and running properly.

Compare the contents of your container with the following parts list to make sure all parts are intact. Any missing parts should be reported to your distributor. Read the instruction manual thoroughly for assembly, maintenance, and safety instructions.

Contents of the Shipping Container

- 1 Band Saw
- 1 Fence
- 1 Feed Screw

- 1 Miter Gauge
- 1 Circle Cutting Attachment
- 1 Shear
- 1 Tool box, containing:
 - 1 Reversible Screwdriver
 - 2 Socket Head Cap Screws, 5/16" x 1"
 - 2 Socket Head Cap Screws, 5/16" x 5/8"
 - 1 Eye Bolt
 - 1 Knob
 - 1 Set of Hex Wrenches
 - 1 Wrench, 26mm
 - 1 Set of Keys for control panel
 - 1 Set of Keys for rear door
- 1 Owner's Manual
- 1 Warranty Card



⚠ WARNING

Read and understand the entire contents of this manual before attempting set-up or operation! Failure to comply may cause serious injury.

Installation and Assembly

Tools required for assembly:

Forklift with strap or chain

Eye bolt (provided)

Set of hex wrenches (provided)

Remove all crating and plastic from around the band saw. Remove any lag screws or holding straps that secure the band saw to the wood pallet.

Remove the eye bolt from the toolbox and screw it into the hole at the top of the machine. Use a forklift with a strap or chain connected to the eye bolt to lift the band saw from the pallet.

Move the band saw to its permanent location, which should be dry, well-ventilated, and well-lit. Leave enough space on all sides to handle long stock or perform routine maintenance on the machine. Make sure the floor is level and can support the machine's weight.

The band saw may be further stabilized by securing it to the floor using lag screws through the four holes in the stand.

Areas of the band saw have been given a protective coating at the factory. This should be removed with a soft cloth moistened with kerosene or mineral spirits. Do not get solvents near plastic or rubber parts, and do not use an abrasive pad as it may scratch metal surfaces.

Fence

Place the fence (Figure 1) onto the groove in the table, as shown, and screw in the knob (from the toolbox) to tighten the fence in position.




Figure 1

Feed Screw

Use two socket head cap screws (provided) to mount the feed screw to the front edge of the

table (Figure 1). Use a 6mm hex wrench to tighten the screws.

Shear

Mount the shear to the back edge of the band saw with two socket head cap screws (provided), as shown in Figure 2.




Figure 2

Circle Cutting Attachment

To use the circle-cutting attachment, mount it on the rod as shown in Figure 3.




Figure 3

Grounding Instructions

⚠ WARNING

Electrical connections must be made by a qualified electrician in compliance with all relevant codes. This machine must be properly grounded to help prevent electrical shock and possible fatal injury.

This machine must be grounded. In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current, reducing the risk of electric shock.

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. The conductor with insulation that is green, with or without yellow stripes, is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.

Check with a qualified electrician or service personnel if the grounding instructions are not completely understood or if in doubt about whether the tool is properly grounded.

Repair or replace a damaged or worn cord immediately.

Make sure the voltage of your power supply matches the specifications on the Band Saw's motor plate. The machine should be connected to a dedicated circuit.

Extension cords

The use of an extension cord is not recommended for this Band Saw. But if one is necessary, make sure the cord rating is suitable for the amperage listed on the machine's motor plate. An undersized cord will cause a drop in line voltage, resulting in loss of power and overheating.

Use the chart in Figure 4 as a general guide for choosing the correct cord size. If in doubt, use the next heavier gauge. The smaller the gauge number, the heavier the cord.

Recommended Gauges (AWG) of Extension Cords

Amps	Extension Cord Length *					
	25 feet	50 feet	75 feet	100 feet	150 feet	200 feet
< 5	16	16	16	14	12	12
5 to 8	16	16	14	12	10	NR
8 to 12	14	14	12	10	NR	NR
12 to 15	12	12	10	10	NR	NR
15 to 20	10	10	10	NR	NR	NR
21 to 30	10	NR	NR	NR	NR	NR

*based on limiting the line voltage drop to 5V at 150% of the rated amperes.

NR: Not Recommended.

Figure 4

230 Volt, Three-Phase Operation

The **three-phase** model is factory-wired for 230 volts but can be converted to 460 volts if desired (see "Converting From 230 Volt to 460 Volt"). You may either install a plug or "hard-wire" the band saw directly to a control panel.

If you are connecting a plug, use a proper UL-listed plug suitable for 230-volt operation.

If the band saw is to be hard-wired to a panel, make sure a disconnect is available for the operator. During hard-wiring of the band saw, make sure the fuses have been removed or the breakers have been tripped in the circuit to which the band saw will be connected. Place a warning placard on the fuse holder or circuit breaker to prevent it from being turned on while the machine is being wired.

Converting from 230 Volt to 460 Volt (Three Phase)

To convert from 230 volt to 460 volt:

1. In the band saw's electrical box, change the setting on the dial of the overload relay ("FR" on pages 39 and 40).
2. All rewiring is done in the electrical box only, by moving the jumpers at the terminal block. Reconnect jumpers from 230V to 460V positions as shown in the diagram inside the electrical box. (The diagram is also included in the back of this manual.)
3. If using a plug, install a proper UL-listed plug suitable for 460-volt operation.

IMPORTANT: Consult the diagrams on pages 38-40 for clarification of these changes for the 230V-to-460V conversion.

Three-Phase Test Run

After wiring the band saw, you should check that the wires have been connected properly. Connect the machine to the power source and turn it on for a moment to observe the direction of the blade's movement.

If the blade runs upward instead of downward, **disconnect machine from power**, and switch any two of the three leads in the motor junction box (see "Electrical Connections", page 38).

Adjustments

Blade Removal and Installation

⚠ WARNING Wear leather gloves when removing or installing band saw blades. New blades usually come coiled; to prevent injury, hold the blade with one hand while carefully uncoiling it with the other.

1. Disconnect machine from the power source.
2. Open the upper and lower doors and swing away the guard (Figure 5).
3. Remove the block from the table's front edge (Figure 5).
4. Loosen tension on the blade by turning the tension handwheel (Figure 6) to the left.
5. Remove the worn blade and install the new one, ensuring the teeth face downward as they pass through the slot in the table.
6. Use the tension handwheel to tighten the blade tension.
7. Proceed with "Blade Tension" and "Blade Tracking" before operating the band saw.




Figure 5




Figure 6

Blade Tension

Rotate the blade tension handwheel to the right to increase tension on the blade or to the left to decrease tension on the blade. Initially, set the blade tension to correspond to the width of your blade, as indicated on the tension gauge (Figure 6). As you become familiar with the saw, you may find it necessary to adjust the blade tension from the initial setting, depending on the blade width and the material being worked.

Keep in mind that too much or too little blade tension can cause blade breakage and/or poor cutting performance.

If the band saw is not to be used for a period of time, release tension on the blade – this will prolong its life. First make a note of the specific tension setting for that blade. The tension can then be re-established quickly when operations are resumed.

Blade Tracking

1. Disconnect the machine from the power source.
 2. Open the top blade wheel doors.
 3. Move the gear shift lever into neutral position (straight down).
 4. Move the upper and lower blade guides away from the blade (see "Blade Guides").
 5. Rotate the upper blade wheel by hand, observing the position of the blade as it rides upon the wheel. The blade should track as near the center of the wheel as possible.
 6. If the blade does not track properly, rotate the blade tracking knob (Figure 6) clockwise to move the blade toward the front of the wheel (as viewed from the front of the saw) or counterclockwise to move the blade toward the rear of the wheel. NOTE: This will also move the blade away from or toward the stoppers on the blade guide assemblies, as shown in Figure 7.
- IMPORTANT:** These are sensitive adjustments; make them gradually and allow the blade time to react to the changes.
7. When satisfied, return the upper and lower blade guides close to the blade.
 8. Close upper and lower doors.




Figure 7

Guide Post

For effective cutting and for safety's sake, there should be a minimum amount of space between the top of the workpiece and the bottom of the blade guides. Loosen the locking knob (see Figure 6) and rotate the handwheel (Figure 6) to raise or lower the guide post so that the guides clear the workpiece by about 3/16".

Blade Guides

CAUTION Blade guides must be properly adjusted or damage may occur to the blade and/or guides.

1. Loosen the two socket head cap screws on the guide housing. See Figure 8.
2. Move the guide support forward or backward to match the width of the blade. The front end of the blade guides should be adjusted approximately 1/8" behind the blade teeth. See Figure 8.
3. Tighten the hex cap screws securely.
4. This procedure should be performed on both the upper and lower guide housings.
5. Loosen the socket head cap screws (Figure 9) on the blade guides.
6. Move the blade guides as close to the blade as possible without touching it.
7. Tighten the socket head cap screws (Figure 9).
8. This procedure should be performed on both the upper and lower blade guides.

As the blade guides receive use, they will become worn at the front end. If the blade guides become difficult to adjust, switch the left and right blade guides (Figure 10).

The stopper positioned behind the back edge of the blade (Figure 10) will also become worn with use, and the friction of the shaft with the saw

blade may cause lines in the surface of the stopper. If this occurs, loosen the socket head cap screw, and rotate the stopper to either side to change its position on the blade. Re-tighten socket head cap screw.




Figure 8




Figure 9




Figure 10

Squaring Work Table with Blade

1. Place the table in horizontal position with "0" on the scale (Figure 11).
2. Place a machinist's square on the table and against the blade as shown.
3. If the square is not flush against the blade, loosen the screw below the table (Figure 11) with a 26mm wrench (provided).
4. Tilt the table as needed until the square is flush with the blade. Retighten the screw.
5. Make sure the pointer is set at "0" on the scale. If it needs slight adjustment, loosen the screw and shift the pointer until it aligns with "0". Re-tighten the screw.




Figure 11

Auxiliary Table

1. After the main work table has been set perpendicular to the blade, use a straight edge to confirm that the auxiliary table is level with the main table, as shown in Figure 12. If the auxiliary table is not level with the main table, make adjustments as follows.
2. To tilt the auxiliary table left or right, loosen the screws (A, Figure 12) and turn one of the stops (B, Figure 12) as needed. Re-tighten screws (A, Figure 12) securely after adjustment.
3. To adjust the table front to back, loosen screws (C, Figure 12). Re-tighten screws securely after adjustment.




Figure 12

Replacing Drive Belts

(See Figure 13)

1. Disconnect machine from power source.
2. To remove the **motor drive belt**, loosen the four screws at the base of the motor. Lift up on the motor to slacken and remove the belt.
3. To remove the **air compressor drive belt**, loosen the four hex nuts on the base of the air compressor and slide the compressor in the direction of the motor. After installing a new belt, slide the compressor away from the motor to tension the belt, and re-tighten the four hex nuts.
4. To remove the **gearbox drive belt**, loosen the hex nuts on the base of the lower variator, and slide the lower variator upward to slacken and remove the belt.
5. To remove the **variator belt**, loosen the four hex nuts on the variator and push the variator upward to slacken the belt.
6. After installing new belts, make sure they are tensioned properly.



Figure 13

Band Saw Operation

Consult “Features and Terminology” on page 7 for identification of the controls.

Unlock the control panel using the provided keys.

⚠ WARNING Never operate the band saw without blade covers in place and secured.

Blade Break-In Procedure

New blades are very sharp and, therefore, have a tooth geometry that is easily damaged if a careful break-in procedure is not followed. Consult the blade manufacturer’s literature for break-in of specific blades on specific materials. The following procedure will be adequate, however, for break-in of JET-supplied blades on lower alloy ferrous materials.

1. Use a section of round stock.
2. Operate the saw at low speed. Start the cut with a very light feed rate.
3. When the saw has completed about 1/3 of the cut, increase the feed rate slightly and allow the saw to complete the cut.
4. Keep the feed rate at the same setting and begin a second cut on the same or similar workpiece.
5. When the saw has completed about 1/3 of the cut, increase the feed rate while watching the chip formation until cutting is at its most efficient rate (refer to “Evaluating Cutting Efficiency” below). Allow the saw to complete the cut.
6. The blade is now considered ready for use.

Setting Blade Speed

⚠ CAUTION Rotate the speed setting handwheel only when the band saw is running.

1. Refer to the Speed and Pitch selection chart on page 21. Select the speed setting for the material to be cut.
2. While the machine is NOT running, move the gear shift lever to the required speed setting (high or low). See Figure 14.

⚠ CAUTION Move the gear shift lever only when the machine is NOT running to prevent damage to the gearbox.

3. Start the saw using the pushbutton.

4. Turn the speed setting handwheel (Figure 14) to the required speed. Turning the handwheel clockwise increases speed. Turning counterclockwise decreases speed.




Figure 14

Evaluating Cutting Efficiency

The best way to determine whether the blade is cutting efficiently is to observe the chips formed by the cutting.

- If the chip formation is powdery, then the feed is much too light, or the blade is dull.
- If the chips formed are curled, but colored – blue or straw colored from heat generated during the cut – then the feed rate is too high.
- If the chips are slightly curled and are not colored by heat – the blade is sufficiently sharp and is cutting at its most efficient rate.

Welder Operation

⚠ WARNING Wear eye protection while operating the welder. Use care when handling the blade after welding to avoid burns.

The welding procedure involves the following steps: Shearing the blade, grinding teeth to allow for the weld area, the actual welding, inspection of the blade, annealing, grinding, and a final inspection of the blade. This procedure can be accomplished using the shear and welder assemblies on your band saw. Proceed as follows:

Shearing

Cut the blade to the longest length needed for the band saw. Using the shear to cut your blade will ensure that the blade ends are cut flat, square and smooth.

1. Place the blade in the shear as shown in Figure 15. Make sure the blade is held square with the shear knife, so that the cut will be square with the blade.

2. Position the blade so that the cut is made at a place that allows for uniform spacing of the teeth. See Figure 16.
3. Push down the handle.

IMPORTANT: If a blade has been cut by using snips, the ends of the blade must be ground square before welding them together, as shown in Figure 17.




Figure 15



Figure 16




Figure 17

Removing Teeth

In fine-pitched blades, one or more of the teeth on each side of the cut may need to be removed by grinding so that the weld area of the blade is uniform and the teeth will be uniformly spaced. See Figure 16.

Welding

1. Carefully clean the ends of the blade that will contact the welder jaws. Remove any dirt, oil, scale, and oxide.

⚠ CAUTION

Any rust (oxide) on the blade in the vicinity of the weld must be ground off before the blade can be welded.

2. Turn the pressure knob to the "0" position (pointed downward). NOTE: There will be some resistance when turning the knob.
3. Insert one end of the blade in the left clamp (Figure 18). Position the back edge of the blade against the back edge of the left clamp. Then position the end of the blade midway between the left and right clamps. Tighten the left clamp.
4. Insert the other end of the blade in the right clamp. Position the back edge of the blade against the back of the right clamp. Then butt the ends of the blades together (the blade ends need to be in contact). Tighten the right clamp.
5. Set the pressure selector switch (counterclockwise rotation) to the approximate setting required for the blade width being welded.

⚠ WARNING

Keep hands clear of the weld area and the clamp jaws during welding.

6. Press and hold the weld button (Figure 18). When the weld button is pushed, the left clamp moves to the right to apply pressure to the blade ends. At the same time, sparks will come from the ends of the blade as they are welded. Do not release the weld button until the blade joint is "red hot."
7. Release the weld button and wait 3 or 4 seconds until the blade returns to its original color. Unclamp the blade.
8. Rotate the pressure selector switch back to "0".

⚠ CAUTION

The welder is designed for intermittent use. Repeated welding within a short period of time may cause the welder to overheat.

9. Remove the blade from the clamps, and carefully inspect it. The spacing of the teeth should be uniform, and the weld should be located in the center of the gullet. Misalignment is easily noted at this time from the weld appearance. See Figure 19 for examples of incorrect welds.
10. If the weld is imperfect, refer to the troubleshooting for possible remedies. Make corrections before annealing.




Figure 18




Figure 19

Annealing

The blade must now be annealed, or cooled, at a controlled rate to prevent it from becoming too brittle.

1. Turn the pressure selector knob all the way to the left so the clamp jaws are as close together as possible.
2. Insert the blade into the clamps so that the weld area is centered between them. Secure the blade in the jaws with the clamp handles.
3. Quickly press and release (jog) the anneal button (Figure 18). Repeat the press-and-release process until you see a slightly red glow from the weld area.

⚠ CAUTION

Do not press and hold the anneal push button. The weld will be overheated and will fail due to the excessive heat.

4. Release both blade clamps, allow the blade to cool, then remove it from the clamps.
5. Check the integrity of the weld. Bend the blade to form a radius at the weld point. The size of the radius should be approximately the same as the radius of the band saw drive wheel. The weld must hold and not break or crack after forming the radius. If the weld breaks, cut away the welded area and repeat the welding-annealing process.
6. Check that the welded section is the same thickness as the rest of the blade. If not, grind off excess welding material using the grinder (Figure 20). Figure 21 illustrates some unacceptable grinding.

⚠ CAUTION

If the blade is thicker at the weld than elsewhere, using it may damage the guides.

7. When grinding, do not hit the teeth, grind deeper than the blade thickness, or burn or overheat the weld area. Be sure to remove flash from the back edge of the blade. Any flash or "stub" teeth which project beyond the normal set or height of the other teeth must be ground off.




Figure 20




Figure 21

Clean Up

It is very important that the clamp jaws be kept clean at all times. The jaws, or inserts, must be wiped or scraped clean after every weld. Doing this will ensure better welds by holding proper alignment, preventing flash from becoming embedded in the blade, and preventing shorts or poor electrical contact.

Blade Selection

Using the proper blade for the job will increase your band saw's operating efficiency, reduce the need for maintenance, and improve your productivity. Thus, it is important to follow certain guidelines when selecting a saw blade. Blade breakage, teeth stripping, crooked cuts, and other common complaints are, in most instances, caused by using the wrong blade.

Consider these factors when selecting a blade:

- The type of material you will be cutting.
- The thickness of the workpiece.
- The features of the workpiece, such as bends or curves with small radii.


These factors are important because they involve basic concepts of saw blade design. There are six blade features that are normally changed to meet certain sawing requirements:

1. width
2. gage
3. pitch (number of teeth per inch)
4. tooth form (or shape)
5. the "set" of the teeth
6. the blade material itself

Width

Band saw width is measured from the back of the blade to the tip of the tooth. Always use the widest blade possible that still performs the needed job. Generally, wider blades are used for straight cutting. Narrower blades are used when the part being cut has curves with small radii.

Refer to the chart in Figure 22 to select a width for radius cutting.



The radii in this chart are all based on cutting 1-inch-thick mild steel with manual feed. In order to cut a close-tolerance radius, the following factors, in addition to the blade width, must be considered: thickness, machinability, feed force, and the location of the pivot point. Heavy feed in thick work, for example, results in a barrel-shaped cut.

Figure 22

Gage

Use the standard gage (blade thickness) except when the workpiece's increased thickness reduces accuracy and the width cannot be increased to compensate.

Examples of heavy gage applications:

1. When radius cutting in thick materials.
2. When the maximum width usable on the machine still does not provide sufficient beam strength for the blade. (Beam strength is the blade's resistance to compression caused by strong feeding or the type of material being cut).

Pitch

Pitch is measured in "teeth per inch" (T.P.I.) and can be constant or variable. Figure 23 shows blades with different pitches. A fine pitch (more teeth per inch) will cut more slowly but more smoothly. A coarse pitch (fewer teeth per inch) will cut rougher but faster.

As a rule of thumb, the thicker the workpiece, the coarser the blade pitch. If you have to cut a hard or very brittle material, you will probably want to use a blade with a finer pitch in order to get clean cuts.

Using a blade with too few teeth may cause vibration and a rough cut, while using one with too many teeth may cause the gullets to fill with shavings and overheat the blade.

As a general rule, use a blade that will have no fewer than 6 and no more than 12 teeth in the workpiece at any given time.

The chart on page 21 will aid in determining pitch for a particular job.




Figure 23

Shape

Figure 24 shows common types of tooth shape. Tooth shape affects cutting rate.

The Regular blade, sometimes called a “raker” blade, has evenly spaced teeth that are the same size as the gullets, and a 0-degree rake angle. This is a good general-purpose blade, and often works well with ferrous metals.

The Skip type has fewer teeth and larger gullets, providing the added chip clearance needed for cutting softer, nonferrous materials and non-metallic applications such as wood, plastic, cork, and composite materials.

The Hook blade has larger teeth and gullets and a positive rake angle, which permits better feed and chip removal. It is useful for both cast iron and hard nonferrous alloys.

Variable-tooth blades combine features of the other styles. They generally offer smooth cuts and long blade life, while reducing noise and vibration.




Figure 24

Set

The term “set” refers to the way in which the saw teeth are bent or positioned. Bending the teeth

creates a kerf that is wider than the back of the blade.

Set patterns are usually selected based on the type of material to be cut. Three common set patterns are shown in Figure 25.

The Regular, or Raker, set is generally furnished on blades which have 2 to 24 teeth per inch. These blades have one tooth set to the left, one to the right, and one unset tooth called a raker. The raker set is often used for contour cutting.

The Wave set is generally furnished on blades which have 8 to 32 teeth per inch. This set has groups of teeth bent alternately to left and right, which reduces the strain on individual teeth. Blades with a wave set are used where tooth breakage is a problem, such as when cutting thin stock or when a variety of work is cut without changing blades; also, when the thickness of the workpiece varies, such as when cutting hollow tubing or structural material.

The Straight set has teeth in a consistent, alternating pattern, which is good for fast, basic cuts where a fine finish is not important. This set is also popular for cutting wood and plastics.




Figure 25

Material

Some of the most common blade materials include:

Carbon Steel Blade – widely used because of its general adaptability for all types of work and for its lower cost. Excellent for cutting nonferrous metals and plastics.

High Speed Steel Blade – resists heat generated while cutting to a far greater extent than carbon steel blades. Best suited for cutting nonferrous metals.

Carbide-Tipped Blade – best used for cutting titanium, beryllium, and case hardened materials.

Blade Breakage

Band saw blades are subject to high stresses and breakage may sometimes be unavoidable. However, many factors can be controlled to help prevent most blade breakage. Here are some common causes for breakage:

1. Misalignment of the blade guides.
2. Feeding workpiece too quickly.
3. Using a wide blade to cut a short radius curve.
4. Excessive tension.
5. Teeth are dull or improperly set.
6. Upper guides are set too high off the workpiece.
7. Faulty weld on blade.

Maintenance

⚠ WARNING

Before doing maintenance on the machine, disconnect it from the electrical supply by pulling out the plug or switching off the main switch! Failure to comply may cause serious injury.

Use a brush to loosen accumulated chips and debris. Use a shop vacuum to remove the debris. Make sure the chip brush on the lower band wheel is properly adjusted.

Lubricate the air compressor with air tool oil about every six months, or more frequently if necessary. Unscrew the cap (Figure 26) and add oil. Replace the cap when finished.

Add grease to the gearbox through the grease fitting; also add grease as needed to the worm gear.

If the power cord is worn, cut, or damaged in any way, have it replaced immediately.




Figure 26

The chart (Figure 27) identifies areas that require cleaning and/or lubricating. Use good quality, general-purpose lubricants.
















Machine Part	Lubricant	Frequency
Bearings	Machine oil	Wipe down every day and lubricate every 6 months
Rack and sliding portion of Guide Post	Grease	every 7 days
Gear shift lever	Grease	every 6 months
Worm gear	Grease	every 3 months
Variator pulley	Machine oil	every 3 months
Blade tension screw	Grease	once a month
Air compressor reservoir	Air Tool oil	every 6 months
Weld clamp jaws	-----	clean after each use
Rubber tire	-----	wipe off daily
Work tables	-----	clean daily

Figure 27

Speed and Pitch Chart

Thickness	Sawing speed (M/min) for specified Material & thickness					Pitch (No. of teeth / inch)				
Material	~1/4	1/4~1	1~3	3~6	6~	~1/4	1/4~1	1~3	3~6	6~
High carbon steel	70	60	60	45	45	18	14	10	6	4
Free cutting steel	60	45	40	30	30	18	14	12	6	4
Ordinary tool steel	40	30	30	25	20	24	18	14	8	4
High speed steel	30	25	20	20	20	24	14	12	8	4
Stainless steel	25	20	20	20	20	18	14	10	8	4
Thick iron plate	45	30	20	20	20	18	14	10	8	4
Cast iron	45	40	30	25	20	18	14	12	8	4
Aluminum 108,A108	365	275	180	120	60	18	10	6	3	3
A132,C133	365	275	180	120	60	18	10	6	3	3
13,43,85,4032,6151	550	425	245	150	90	18	10	6	3	3
113,138,152,B-195	550	380	275	180	90	18	10	6	3	3
B-214,312,333	550	380	275	180	90	18	10	6	3	3
212,355,356,360,380	550	380	275	180	90	18	10	6	3	3
142,195,750	915	825	735	670	610	18	10	6	3	3
2014,2018,2025	915	825	735	670	610	18	10	6	3	3
6053,7075	915	825	735	670	610	18	10	6	3	3
6061,6063	1500	1220	1065	915	770	18	10	6	3	3
122,214,218,220	1500	1385	1220	1065	915	18	10	6	3	3
1100,2011,2017,3003,3004	1500	1500	1500	1385	1220	18	10	6	3	3
2024,5052	1500	1500	1500	1500	610	18	10	6	3	3
Magnesium bronze	125	75	40	25	20	14	8	6	3	3
Leaded commercial bronze	915	610	450	305	150	14	8	6	3	3
Commercial bronze	150	105	60	30	20	14	8	6	3	3
Free cutting brass	1220	915	610	450	300	14	8	6	3	3
Forging brass	610	460	335	245	150	14	8	6	3	3
High leaded brass	1065	825	565	410	260	14	8	6	3	3
Leaded brass	610	460	275	215	150	14	8	6	3	3
Low loaded brass	455	305	150	60	20	14	8	3	3	3
Leaded copper	765	550	360	240	120	14	8	3	3	3
Cadmium copper	90	60	30	25	20	14	8	3	3	3
Magnesium	1500	1385	1220	915	610	14	8	3	3	3
Cadmium	1220	1065	915	915	760	14	8	6	3	3
Manganese	60	45	30	25	20	24	14	6	3	3
Nickel	55	40	30	25	20	18	14	6	3	3
Molybdenum	55	45	40	35	25	18	14	6	3	3
Chrome	50	40	25	20	20	18	14	6	3	3
Silicon	55	30	30	20	20	18	14	6	3	3
Carbon (8~35)	1220	1065	915	765	610	10	6	3	3	3
Carbon (35~65)	615	245	90	45	20	14	10	6	3	3
Carbon (1008~ 1095)	60	45	30	25	20	24	14	6	3	3
Rubber	460	155	90	60	45	18	14	10	8	6
Plastics	1500	1065	765	550	455	10	8	3	3	3

Typical Band Saw Operations

 RIPPING	 SLICING	 BEVELING
 SLOTTING	 SEGMENTING	 SHAPING CUT
 SPLITTING	 ANGULAR CUT	 GRINDING RELIEF
 STACK CUTTING	 EXTERNAL CONTOUR	 INTERNAL CONTOUR
 THREE-DIM. CUTTING	 SHAPING	 COMPOUND ANGLE CUT

Troubleshooting – Operating Problems

Trouble	Probable Cause	Remedy
Saw blade is twisted.	Blade has been improperly welded.	Re-weld the blade (see pages 14-17).
	Blade not installed properly.	Set the guide inserts closer and increase blade tension.
	Feeding workpiece too forcefully.	Decrease feed rate.
	Incorrect choice of blade.	Use a proper width blade for radius or wavy line cutting.
Cuts not straight.	Blade tooth has improper set.	File to proper set or replace blade.
	Not enough blade tension.	Increase tension.
	Guide post too high.	Set guide post closer to the workpiece.
	Feed rate too strong.	Decrease feed rate.
Blade slips off wheel(s).	Blade not tensioned enough.	Increase tension.
	Wheels not aligned properly.	Contact technical service for adjustment of wheel alignment.
Blade quickly becomes dull.	Blade speed too fast.	Use slower speed.
	Wrong blade for the job.	Use proper blade for workpiece.
	Feed rate excessive.	Decrease feed rate.
Blade warps.	Dull blade.	Sharpen or replace blade.
	Guide post not fixed properly.	Fix guide post in position.
	Blade not tensioned enough.	Increase tension.
	Blade not 90° to table.	Adjust table perpendicular to blade (see page 13).
Band Saw is noisy, or vibrates too much.	Band Saw not resting on level surface.	Floor must be flat.
	The variator pulley is damaged.	Replace pulley.
Blade teeth keep breaking.	Incorrect blade for the job.	Select proper blade pitch and style.
	Blade is of inferior material.	Use better quality blade.
Blade becomes damaged easily.	The blade has been over-annealed.	Decrease annealing temperature.
	Too large a gap between blade guides and blade.	Adjust proper gap between guides and blade (see page 12).
	Blade too wide for short radius cutting.	Select narrower blade appropriate to the job.

Troubleshooting – Mechanical and Electrical Problems

Trouble	Probable Cause	Remedy
Machine will not start/restart or repeatedly trips circuit breaker or blows fuses.	No incoming power.	Verify machine is connected to power source. Make sure START button is pushed in completely, and the STOP button is disengaged.
	Cord damaged.	Replace cord.
	Overload automatic reset has not reset.	When the band saw overloads on the circuit breaker built into the motor starter, it may take time for the machine to cool down before restart. Allow unit to adequately cool before attempting restart. If problem persists, check amp setting on the motor starter.
	Band Saw frequently trips.	One cause of overloading trips which are not electrical in nature is too heavy a cut. The solution is to reduce feed pressure into the blade. If too heavy a cut is not the problem, then check the amp setting on the overload relay. Match the full load amps on the motor as noted on the motor plate. If amp setting is correct then there is probably a loose electrical lead. Check amp setting on motor starter.
	Building circuit breaker trips or fuse blows.	Verify that band saw is on a circuit of correct size. If circuit size is correct, there is probably a loose electrical lead. Check amp setting on motor starter.
	Switch or motor failure (how to distinguish).	If you have access to a voltmeter, you can separate a starter failure from a motor failure by first, verifying incoming voltage at 220+/-20 and second, checking the voltage between starter and motor at 220+/-20. If incoming voltage is incorrect, you have a power supply problem. If voltage between starter and motor is incorrect, you have a starter problem. If voltage between starter and motor is correct, you have a motor problem.
	Motor overheated.	Clean motor of dust or debris to allow proper air circulation. Allow motor to cool down before restarting.

Trouble	Probable Cause	Remedy
Machine will not start/restart or repeatedly trips circuit breaker or blows fuses.	Motor failure.	If electric motor is suspect, you have two options: Have a qualified electrician test the motor for function or remove the motor and take it to a qualified electric motor repair shop and have it tested.
	Miswiring of the unit.	Double check to confirm all electrical connections are correct. Refer to appropriate wiring diagrams on pages 38 and 39 to make any needed corrections.
	Switch failure.	If the start/stop switch is suspect, you have two options: Have a qualified electrician test the switch for function or purchase a new start/stop switch and establish if that was the problem on changeout.
Band Saw does not come up to speed.	Extension cord too light or too long.	Replace with adequate size and length cord.
	Low current.	Contact a qualified electrician.

Troubleshooting – Welded Blade Inspection

Trouble	Probable Cause	Remedy
Weld is misaligned.	Dirt or scale on clamp jaws or blade.	Always keep jaws clean. Clean blade before welding.
	Blade ends not square.	Before welding, grind cut edges of the blade until they are square. Use the shear on the band saw for square cuts.
	Blade ends not correctly aligned when clamped in jaws.	Align the ends properly before clamping.
	Worn clamp jaws	Replace clamp jaws.
	Clamp jaws not aligned correctly.	Align jaws correctly.
Misaligned weld: Blade ends are overlapped.	Pressure knob is set for wider blade than the one used.	Adjust the pressure knob correctly for particular blade width.
	Blade ends or clamp jaws not aligned correctly.	Make corrections as needed.
Weld breaks when used.	Weld is weak and incomplete; possible “blow holes” (see Figure 19).	Cut and re-weld the blade ends.
	Weld has been ground too thin.	Cut and re-weld the blade ends.
	Weld is not annealed correctly.	Follow annealing instructions on page 16.
Incomplete weld.	Pressure knob not set correctly.	Make appropriate adjustment
	Improper clamping procedures.	Follow instructions on pages 14 through 17.
	Limit switch (#1, page 35) not adjusted correctly.	Adjust limit switch correctly.
	Defective limit switch; doesn't break circuit at end of welding operation.	Replace limit switch.
	Clamp jaw movement obstructed by kinked jaw cable or tangled wires.	Bend cable and untangle wires.
Brittle weld.	Incorrect annealing heat.	Bring weld up to correct color (see page 16).
	Scale or oil on weld caused poor annealing.	Keep clamp jaws and blade clean.

Troubleshooting – Welder Mechanical Problems

Trouble	Probable Cause	Remedy
Weld could not be made. Jaws do not move.	Wire connection is poor; connecting point of welding switch is bad.	Change switch or grind the connecting port with a file.
	Transformer burnt out.	Change transformer, or re-wire it.
	Blade has oil on it.	Wipe off any oil.
	Blade ends have rust on them.	Grind off the rust.
Weld area melts when weld switch is pushed.	Welding switch is cutting off too late.	Screw the welding switch connecting nut tighter.
	Welding press is too weak.	Rotate the pressure selector knob accordingly.
	Jaw movement is too slow.	Put some oil on the rear side of the welding lever and the two jaws.
Blade cannot be tightly clamped with the clamp jaws.	Clamp jaws are out of order or decayed.	Replace clamp jaws.
	Lower jaw inserts are out of order.	Replace lower jaw inserts.
Annealing doesn't occur when the annealing button is pushed.	Annealing switch connection is poor.	Change the annealing switch.
	Fuse is blown.	Replace fuse.
Annealing button will not return to correct position after it is released.	Annealing button has dust or debris around it.	Remove the annealing button housing and clean out any dust or debris.
Grinder will not run when the Grinder switch is pushed.	Grinder motor is burnt out.	Change grinder motor or re-wire it.
	Grinder switch is bad.	Replace grinder switch.

Replacement Parts

Replacement parts are listed on the following pages. To order parts or reach our service department, call 1-800-274-6848 Monday through Friday, 8:00 a.m. to 5:00 p.m. CST. Having the Model Number and Serial Number of your machine available when you call will allow us to serve you quickly and accurately.

Parts List: VBS-3612 Band Saw

(refer to breakdowns on pages 33 and 34)

Index No.	Part No.	Description	Size	Qty
1	JT9-VBS16-050CP	Gear Box		1
2	JT9-TS-0209101	Socket Head Cap Screw	3/8"-16 x 2-1/4"	4
3	JT9-TS-0720091	Lock Washer	3/8"	26
4	JT9-TS-0680041	Flat Washer	3/8"	24
5	JT9-TS-0271091	Set Screw	3/8"-16 x 1"	4
6	JT9-VBS3612-106	Oil Seal	Φ40 x Φ30 x 7mm	1
7	JT9-VBS3612-107	Oil Seal	Φ52 x Φ30 x 7mm	1
8	JT9-VBS3612-108	Gear Box Cover		1
9	JT9-TS-0050011	Hex Cap Screw	1/4"-20 x 1/2"	4
10	JT9-TS-0720071	Lock Washer	1/4"	6
11	JT9-TS-0680021	Flat Washer	1/4"	6
12	JT9-VBS3612-112	Gear		1
13	JT9-VBS3612-113	Key	6 x 35mm	1
14	JT9-VBS3612-114	Oil Seal	Φ30 x Φ19 x 8mm	1
15	JT9-VBS3612-115	Retaining Ring	30	1
16	JT9-VBS3612-116	Gear		1
17	**	Screw Nut	35mm	1
18	JT9-VBS3612-118	Screw Nut	26mm	1
19	**	Gear		1
20	JT9-VBS3612-120	Gear Shaft		1
21	JT9-VBS3612-121	Key	1/4 x 5/8"	2
22	JT9-VBS3612-122	Shaft Cover		1
23	JT9-TS-0207041	Socket Head Cap Screw	1/4"-20 x 3/4"	9
24	**	Gear		1
25	JT9-VBS3612-125	Main Shaft		1
26	JT9-VBS3612-126	Retaining Ring	30mm	1
27	JT9-VBS3612-127	Main Shaft Cover		1
28	JT9-VBS3612-128	Oil Seal	Φ58 x Φ40 x 8mm	1
29	JT9-VBS3612-129	Speed Changing Shaft		1
30	JT9-VBS3612-130	Speed Changing Arm		1
31	JT9-TS-0561011	Hex Nut	1/4"-20	3
32	JT9-VBS3612-132	Shaft Stopper		1
33	JT9-TS-0270051	Socket Set Screw	5/16"-18 x 1/2"	1
34	JT9-VBS3612-134	Spring		1
35	JT9-VBS3612-135	Slide Block		1
36	JT9-VBS3612-136	Clutch		1
37	JT9-VBS3612-137	Brass Bushing		2
38	JT9-VBS3612-138	Brass Bushing		1
39	JT9-VBS3612-139	Speed Changing Lever		1
40	JT9-VBS3612-140	Shaft Housing		1
41	JT9-VBS3612-141	Socket Head Cap Screw	10-24 x 5/8"	3
42	JT9-VBS3612-142	Speed Lever Ring		1
43	CM9-9052321	Socket Head Cap Screw	3/8"-16 x 3/4"	1
44	JT9-VBS3612-144	Pulley	10" A2	1
45	JT9-TS-0209061	Socket Head Cap Screw	3/8"-16 x 1-1/4"	9
46	JT9-VBS3612-146	Lever Knob		1
47	JT9-BB-6008	Ball Bearing	6008	1
48	CM9-BB-6206	Ball Bearing	6206	1
49	JT9-BB-6304	Ball Bearing	6304	1
	JT9-VBS3612-149A	Work Table (not shown)		1
50	JT9-VBS3612-150G	Table Support Frame		1
51	JT9-TS-0060071	Hex Cap Screw	3/8"-16 x 1-1/2"	4
52	JT9-VBS3612-152G	Table Support Housing		1
53	**	Socket Head Cap Screw	1/2"-12 x 2"	4
54	JT9-TS-0720111	Lock Washer	1/2"	8
55	JT9-TS-0680061	Flat Washer	1/2"	8

Index No.	Part No.	Description	Size	Qty
56	JT9-TS-0561021	Hex Nut	5/16"-18	4
57	JT9-VBS1220M-110G	Guide Support Housing		1
58	JT9-TS-0208061	Socket Head Cap Screw	5/16"-18 x 1"	4
59	JT9-TS-0720081	Lock Washer	5/16"	34
60	JT9-TS-0680031	Flat Washer	5/16"	31
61	CM9-TS-1503061	Socket Head Cap Screw	M6 x 25	2
62	JT9-VBS3612-162	Right-Handed Screw	1/4 x 1"	1
63	JT9-TS-0207061	Socket Head Cap Screw	1/4-20 x 1"	2
64	JT9-VBS3612-164	Left-Handed Screw		1
65	JT9-VBS3612-165	Slider		1
66	JT9-VBS3612-166	Table Tilt Adjust Screw		1
67	JT9-VBS3612-167	Auxiliary Table		1
68	JT9-VBS3612-168G	Auxiliary Table Support Frame		1
69	JT9-VBS3612-169G	Table Bracket		2
70	JT9-TS-0209061	Socket Head Cap Screw	3/8"-16 x 1-1/4"	4
71	JT9-TS-0209081	Socket Head Cap Screw	3/8"-16 x 1-3/4"	4
72	JT9-VBS3612-172G	Bracket		1
73	JT9-TS-0561031	Hex Nut	3/8"-16	4
74	JT9-VBS3612-174	Adjust Screw		2
75	JT9-VBS3612-175	Miter Gauge		1
76	JT9-TS-0208071	Socket Head Cap Screw	5/16"-18 x 1-1/4"	3
77	JT9-TS-1503021	Socket Head Cap Screw	M6 x 10	8
78	JT9-TS-1534032	Phillips Pan Head Machine Screw	M5 x 8	1
79	JT9-TS-2361051	Lock Washer	M5	19
80	JT9-VBS2012-1550	Rip Fence		1
81	JT9-VBS3612-181	Circle Cutting Attachment		1
82	JT9-TS-0208061	Socket Head Cap Screw	5/16"-18 x 1"	2
83	JT9-VBS3612-183	Hex Cap Screw	1/4"-20 x 2-3/4"	1
	JT9-VBS3612-184	Holding Jaw (not shown)		1
85	JT9-VBS3612-185	Feed Screw		1
	PR9-VBS3612-1800	Feed Jaw Assembly		1
86	JT9-VBS3612-186	Magnifying Glass		1
87	JT9-TS-1533032	Phillips Pan Head Machine Screw	M5 x 10	2
88	JT9-TS-1550031	Flat Washer	M5	2
89	JT9-VBS3612-189	Blade Guide Support		1
90	JT9-VBS3612-190	Blade Guide Support		1
91	JT9-VBS1220A-132	Blade Guides		4
92	CM9-TS-1503061	Socket Head Cap Screw	M6 x 25	4
93	JT9-TS-1551041	Lock Washer	M6	10
94	CM9-TS-1550041	Flat Washer	M6	4
95	JT9-VBS3612-195	Blade Stopper		1
96	JT9-VBS3612-196	Blade Stopper		1
97	JT9-VBS2012-1350	Blade Guide Post		1
98	JT9-VBS2012-1351	Gear Rack		1
99	JT9-TS-0206022	Socket Head Cap Screw	10-24 x 1/2"	3
100	JT9-VBS2012-1360	Guide Post Housing		1
101	JT9-VBS3612-1101G	Blade Guard, Left		1
102	JT9-VBS3612-1102	Blade Guard, Right		1
103	JT9-VBS2012-1400	Spring		2
104	JT9-VBS2012-1410	Spring Locker		1
105	**	Socket Head Cap Screw	1/4"-20 x 1-1/4"	2
106	JT9-VBS3612-1106	Post Housing Spring		1
107	JT9-VBS2012-1450	Post Elevating Gear		1
108	JT9-5051911	Flat Washer	M10	1
109	JT9-TS-1540071	Hex Nut	M10	2
110	JT9-VBS3612-1110	Guide Post Locker		1
111	JT9-VBS3612-1111	Handwheel		1
112	JT9-TS-0270051	Socket Set Screw	5/16"-18 x 1/2"	1
113	JT9-VBS3612-1113	Handwheel Knob		1

Index No.	Part No.	Description	Size	Qty
114	JT9-VBS3612-1114	Main Drive Motor	3HP 3PH	1
115	JT9-TS-0051051	Hex Cap Screw	5/16"-18 x 1"	8
116	JT9-VBS3612-1116	Motor Pulley		
		(serial no: 13033613 and lower)	4-1/8" A3	1
	JT9-VBS3612-1116N	Motor Pulley		
		(serial no: 13033614 and higher)	65mm	1
117	JT9-VB-A44	V-Belt	2010+7070	2
	JT9-VB-A43	V-Belt (serial no. 13123617 and higher)	A43	2
118	JT9-VB-A50	V-Belt	7300+7071	2
119	JT9-BA62	V-Belt (serial no. 13033613 and lower)	2010+4450	1
	JT9-BA59	V-Belt (serial no. 13033614 and higher)		1
120	JT9-VBS2012-BV875	V-Belt	7020+7220	1
121	JT9-VBS1220A-301	Lower Wheel		1
122	JT9-VBS1220A-302	Rubber Tire		2
123	JT9-VBS3612-1123	Rubber Tire		1
124	JT9-VBS2012-3030	Tapered Sleeve		1
125	JT9-VBS2012-3040	Wheel Locking Nut		1
126	JT9-VBS1220A-305	Upper Wheel		1
127	JT9-VBS3612-1127	Auxiliary Wheel		1
128	JT9-VBS2012-3060	Upper Wheel Lock		2
	JT9-VBS2012-3070	Upper Wheel Nut (not shown)		1
130	**	VBS2012-3080CP ... Slide Block Housing		1
131	JT9-TS-0209051	Socket Head Cap Screw	3/8"-16 x 1"	10
132	JT9-VBS3612-1132	Auxiliary Wheel Shaft		1
133	JT9-TS-0271071	Socket Set Screw	3/8"-16 x 3/4"	4
134	**	Slide Block Seat		1
135	JT9-VBS2012-3100	Slide Block Guide		2
136	JT9-TS-0209071	Socket Head Cap Screw	3/8"-16 x 1-1/2"	4
137	JT9-VBS2012-3110A	Upper Wheel Slider		1
138	JT9-TS-0267041	Socket Set Screw	1/4"-20 x 3/8"	4
140	JT9-VBS2012-3112	Slide Screw Shaft		1
	PR9-VBS2012-3116	Slide Screw Shaft Assembly (includes #129,140)		1
142	JT9-VBS2012-3120	Wheel Elevation Shaft		1
143	JT9-VBS2012-3121	Spring		1
144	**	Washer		1
145	JT9-VBS2012-3180	Indicator Rings		3
146	**	Tension Indicator		1
147	JT9-VBS2012-3200	Wheel Tilt Adjuster		1
148	JT9-VBS2012-3220	Wheel Tilt Connector		1
149	JT9-VBS2012-3240	Connector Washer		1
150	JT9-VBS3612-1150	Connector Housing		1
151	JT9-TS-1504041	Socket Head Cap Screw	M8 x 20	3
152	JT9-VBS2012-9030	Handwheel		1
153	JT9-TS-0208031	Socket Head Cap Screw	5/16"-18 x 5/8"	2
154	JT9-VBS3612-1154	Wheel Tilt Knob		1
155	JT9-G6205	Ball Bearing	6205	2
156	CM9-BB-6305	Ball Bearing	6305	2
157	JT9-VBS3612-1157	Air Pump Suspension Arm		2
158	JT9-TS-0208041	Hex Cap Screw	5/16"-18 x 3/4"	4
159	JT9-VBS2012-4170	Air Nozzle		1
160	JT9-VBS2012-4180	Air Nozzle Clip		1
160-1	**	Air Hose		1
4450	JT9-VBS3612-1161	Air Compressor		1
162	**	Main Body		1
163	JT9-VBS3612-1163G	Rear Door, Right		1
164	JT9-VBS3612-1164G	Rear Door, Left		1
165	JT9-TS-1533032	Pan Head Screw	M5 x 10	14
166	JT9-VBS3612-1166G	Front Lower Door		1
167	JT9-VBS3612-1167G	Front Upper Door, Right		1

Index No.	Part No.	Description	Size	Qty
168	JT9-VBS3612-1168G	Front Upper Door, Left		1
169	JT9-VBS3612-1169	Upper Door Hinge		4
170	JT9-TS-1533032	Phillips Pan Head Machine Screw	M5 x 10	12
171	JT9-TS-1540031	Hex Nut	M5	10
172	JT9-TS-1533052	Phillips Pan Head Machine Screw	M5 x 16	8
173	JT9-VBS3612-1173	Hinge		6
174	JT9-VBS3612-1174	Spring Plate		6
175	JT9-VBS3612-1175	Handle Arm		3
176	JT9-TS-1534052	Phillips Pan Head Machine Screw	M6 x 16	6
177	CM9-TS-2311061	Hex Nut	M6	6
	**	Chip Stopper (not shown)		1
179	JT9-TS-2288202	Phillips Pan Head Machine Screw	M8 x 12	3
180	JT9-VBS3612-1180	Pointer		1
181	JT9-VBS2012-9780	Brush Bracket		1
182	CM9-TS-2361081	Lock Washer	M8	1
183	JT9-TS-0050031	Hex Cap Screw	1/4"-20 x 3/4"	1
184	JT9-VBS2012-9790	Chip Brush		1
185	JT9-VBS3612-1185	Eye Bolt		1
186	JT9-VBS2012-6600	Push button, On		1
187	JT9-VBS2012-6602	Push button, Off		1
188	JT9-VBS2012-6610	Emergency Stop Switch		1
189	JT9-VBS3612-1189	Limit Switch		3
190	JT9-VBS2012-6650	Key Switch		1
191	JT9-VBS3612-1191	Main Switch		1
192	JT9-TS-2284301	Phillips Flat Head Machine Screw	M4 x 20	2
193	JT9-VBS3612-1193	Contactors		1
194	JT9-TS-1532052	Phillips Pan Head Machine Screw	M4 x 15	8
195	JT9-VBS3612-1195	Overload Relay		1
196	JT9-VBS2012-6742	Pilot Light, Green (Power)		1
197	JT9-VBS3612-1197	Voltage Reducer		1
198	JT9-TS-2284082	Phillips Pan Head Machine Screw	M4 x 8	16
199	**	Fuse Block		3
200	JT9-TS-1534052	Phillips Pan Head Machine Screw	M6 x 15	3
201	**	Fuse Holder		2
202	**	Fuse Holder		1
203	JT9-VBS3612-1203	Wire Housing		3
204	JT9-VBS3612-1204	Ground Seat		1
205	JT9-VBS3612-1205G	Electrical Box		1
206	CM9-TS-1502081	Socket Head Cap Screw	M5 x 35	2
207	JT9-VBS3612-1207G	Wiring Plate		1
208	JT9-TS-0810012	Round Head Screw	10-24 x 1/4"	4
	JT9-VBS3612-1209	Wiring Duct (not shown)		1
210	**	Control Plate		1
211	JT9-VBS3612-1211	Copper Pan Head Screw	M4 x 10	6
212	**	Indicator Plate		1
213	JT9-VBS2012-8372	Variator Instruction		1
214	JT9-VBS2012-8422	Gear Box Instruction		1
215	JT9-VBS3612-1215	Tilt Indicator Scale		1
216	**	Motor Spring Housing		1
217	JT9-TS-0051061	Hex Cap Screw	5/16"-18 x 1-1/4"	16
218	JT9-VBS2012-7010	Spring		1
219	JT9-VBS3612-1219	Variator Disk, Upper Outer		1
220	JT9-TS-0208041	Socket Head Cap Screw	5/16"-18 x 3/4"	3
221	JT9-VBS2012-7030	Variator Disk, Upper Inner		1
222	JT9-VBS2012-7040	Variator Housing Tube		1
223	JT9-VBS3612-1223	Variator Disk Shaft		1
224	JT9-TS-1501051	Socket Head Cap Screw	M4 x 16	3
225	JT9-VBS3612-1225	Key	6 x 80mm	1
226	JT9-VBS2012-7060	Variator Housing		1

Index No.	Part No.	Description	Size	Qty
227	JT9-VBS3612-1227	Retaining Ring	16	1
228	JT9-VBS3612-1228	Pulley	9" A2	1
229	JT9-TS-0209051	Socket Head Cap Screw	3/8"-16 x 1"	1
230	JT9-VBS2012-7080	Worm Gear		1
231	JT9-TS-0207031	Socket Head Cap Screw	1/4"-20 x 5/8"	1
232	JT9-VBS2012-7090	Worm Gear Housing		1
233	CM9-TS-0267061	Set Screw	1/4"-20 x 5/8"	4
234	JT9-VBS2012-7100	Gear Shaft		1
235	JT9-VBS2012-7110	Worm		1
236	JT9-TS-0267041	Socket Set Screw	1/4"-20 x 3/8"	1
237	JT9-VBS2012-7120	Arm		1
	JT9-VBS2012-7190	Screw Nut (not shown)		1
239	JT9-BB-6007	Ball Bearing	6007	2
240	JT9-VBS2012-7200	Spring Housing		1
241	JT9-VBS2012-721	Spring		1
242	JT9-VBS2012-7220	Variator Disk, Lower Outer		1
243	JT9-VBS2012-7230A	Variator Disk, Lower Inner		1
	JT9-VBS2012-7230A	Variator Shaft (not shown)		1
245	JT9-VBS3612-1245	Key	6 X 60mm	1
	JT9-VBS3612-VDLI	Variator Disk, Lower Inner Assembly (includes 243,244,245,224)		1
246	JT9-VBS3612-1246	Shaft Housing		1
247	JT9-VBS2012-7290	Spacer		1
248	JT9-VBS3612-1248	Socket Head Cap Screw	10-24 x 5/8"	3
249	JT9-VBS3612-1249	Pulley	4-1/8" A2	1
250	JT9-VBS3612-1250	Speed Readout Detector		1
251	**	Digital Tachometer		1
252	CM9-BB-6204	Ball Bearing	6204	1
253	JT9-TS-1502021	Socket Head Cap Screw	M5 x 10	1
254	JT9-TS-1524041	Socket Set Screw	M8 x 16	1
255	JT9-BB-6303	Ball Bearing	6303	1
256	**	Blade Guard		2
257	**	Handle Screw		1
258	**	Blade Guard Left		1
259	**	Retaining Ring, Internal	RR62	1
260	JT9-F006054	Retaining Ring, External	RS35	1
261	**	Retaining Ring, Internal	RR52	1
262	JT9-F006050	Retaining Ring, External	RS25	1
263	JT9-F006047	Retaining Ring, External	RS20	2
264	JT9-F006075	Retaining Ring, Internal	RR47	1
265	PR9-VBS3612-9850	Key		1
266	**	Motor Rotary Seat		1
267	**	Flat Washer		1
268	**	Hex Socket Cap Screw	3/8"x2-1/4"	1
269	**	Chip Stopper		1


** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

Optional Accessories


Stock No	Description
JT9-5674030	Replacement Blade – 1/4" x .025" x 197" x 14R-C

VBS-3612 Band Saw

CLH-



VBS-3612 Band Saw



Parts List: Welder, Shear and Work Lamp Assemblies


(refer to breakdown on page 37)

Index No.	Part No.	Description	Size	Qty
1	JT9-JWG34-601	Limit Switch		1
2	**	Insulator		1
3	JT9-VBS3612-203	Pan Head Bolt	1/8"-32 x 5/8"	2
4	JT9-TS-0720051	Lock Washer	1/8"	2
5	JT9-JWG34-602	Guide Block		1
6	JT9-TS-1502061	Socket Head Cap Screw	M5 x 25	2
7	JT9-TS-1551031	Lock Washer	M5	2
8	JT9-JWG34-602	Spring Bracket		1
9	JT9-TS-1533032	Phillips Pan Head Machine Screw	M5 x 8	2
10	**	Guide Casting		1
11	CM9-TS-1534041	Flat Head Screw	M5 x 10	4
12	**	Housing		1
13	JT9-TS-1533052	Phillips Pan Head Machine Screw	M5 x 16	6
14	JT9-PR-EV-6050	Stationary Jaw		1
15	JT9-TS-1502051	Socket Head Cap Screw	M5 x 20	3
16	JT9-PR-EV-6051	Insulator		1
17	**	Insulating Tubes		3
18	**	Washer, Insulate		3
19	**	Spacers		3
20	**	Eccentric Shafts		2
21	**	Clamp Lever, Right		1
22	**	Round Head Screw	5/16"-18 x 3/4"	2
23	JT9-TS-0561021	Hex Nut	5/16"-18	2
24	**	Clamp Lever, Left		1
25	JT9-JWG34-610R	Clamp Support, Right		1
26	JT9-JWG34-610L	Clamp Support, Left		1
27	JT9-JWG34-610R	Clamp Plate, Right		1
28	JT9-TS-1533032	Phillips Pan Head Machine Screw	M5 x 8	4
29	JT9-TS-1551031	Lock Washer	M5	2
30	JT9-JWG34-610L	Clamp Plate, Left		1
31	JT9-PR-EV-6120	Retaining Ring (Re7)		2
32	**	Moving Jaw		1
33	JT9-TS-1502031	Socket Head Cap Screw	M5 x 12	2
34	JT9-JWG34-615	Weld Button (6150/6160)		1
36	**	Pressure Adjust Knob		1
37	**	Shaft		1
38	JT9-TS-0720071	Lock Washer	1/4"	5
38-1	JT9-TS-1482031	Hex Cap Screw	M6x16	1
39	JT9-TS-0680021	Flat Washer	1/4"	5
40	JT9-TS-0561011	Hex Nut	1/4"-20	3
41	JT9-JWG34-620	Cam		1
42	**	Weld Tension Arm		1
43	JT9-TS-081F052	Phillips Pan Head Machine Screw	1/4"-20 x 5/8"	1
44	**	Bushing		1
45	**	Spring, Short		1
46	JT9-JWG34-623	Spring, Long		1
47	JT9-VBS3612-247	Pan Head Screw	M5 x 25	1
48	JT9-TS-1540031	Hex Nut	M5	1
49	JT9-VBS1220M-624	Transformer		1
50	JT9-VBS3612-250	Copper Pan Head Screw	10-24 x 3/8"	2
51	JT9-TS-1551031	Lock Washer	3/16"	2
52	**	Mounting Bracket		1
53	CM9-TS-1534041	Flat Head Screw	M5 x 12	10
54	JT9-TS-0050171	Hex Cap Screw	1/4"-20 x 4"	2
55	JT9-JWG34-625	Switch		1
56	JT9-JWG34-626	Grinder Motor		1


Index No.	Part No.	Description	Size	Qty
57	JT9-PR-EV-6270	Spacer	M6	1
58	JT9-JWG12-628	Grinder Wheel		1
59	JT9-TS-0680021	Flat Washer	M6	1
60	CM9-TS-2311061	Hex Nut	M6	1
61	JT9-VBS1220M-629	Grinder Guard		1
62	JT9-JWG34-629A	Grinder Cover		1
63	JT9-JWG34-633	Welder Name Plate		1
65	**	Instruction Label		1
66	JT9-JWG12-616CP	Grinder Label		1
67	**	Anneal Button		1
68	JT9-VBS3612-268	Deflector Bracket, Right		1
69	JT9-VBS3612-269	Pan Head Screw	M4 x 8	4
70	JT9-VBS3612-270	Wood Screw	1/8 X 1/4"	2
71	JT9-VBS3612-271	Deflector Bracket, Left		1
72	JT9-VBS3612-272	Spark Deflector		1
73	PR9-PR-EV-9290	Knobs		2
94	**	Spindle Bushings		3
95	JT9-TS-0207031	Socket Head Bolt	1/4 X 5/8"	1
96	JT9-TS-0207081	Socket Head Bolt	1/4 X 1 1/2"	1
97	**	Spindle Lift		1
98	JT9-VBS3612-298	Retaining Ring	5mm	2
99	**	Blade Shaft		1
100	JT9-VBS3612-2100	Retaining Ring	25mm	2
101	**	Vaned Iron Plates		2
102	JT9-VBS3612-2102	Pan Head Bolt	3/16 X 3/8"	4
103	JT9-JWG34-195A	Lower Blades		2
104	JT9-VBS2012-SCP	Upper Blade		1
105	**	Joint Plate, Left		1
106	JT9-TS-0208031	Socket Head Bolt	5/16 X 5/8"	2
107	JT9-TS-0720081	Lock Washer	5/16"	2
108	**	Chain Joint, Right		1
109	JT9-JWG34-199A	Handle Bar		1
110	JT9-PR-EV-9210	Knob		1
111	JT9-VBS3612-WL	Work Lamp Assembly	110/ 12V 20W	1
112	**	Switch Bracket		1
113	JT9-PR-EV-6160	Micro Switch		1
114	**	Wood Screw		1
115	JT9-TS-081B062	Pan Head Screw	5/32"x1"	2

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.



Welder, Shear and Work Lamp Assemblies



Electrical Connections – 3Ph, 230/460V




Electrical Connections – 3Ph, 230/460V



SB1	Weld On (White)	SA4	Key Switch	SQ6	Safety Switch
SB2	Anneal On (Green)	HL	Indicator Light (Green)	KM	Contactor
SB3	Emergency Stop (Red)	EL	Lamp (20W/12V, 110V)	FR	Overload Relay
SB4	Main Motor Off (Red)	QS	General Switch	T2	Transformer
SB5	Main Motor On (Green)	SQ1	Safety Switch		
SA1	Grinder Motor On	SQ2	Safety Switch		
SA2	Work Lamp On (Black)	SQ5	Weld Auto Stop		

Electrical Box

(see page 38 for identification of parts)





427 New Sanford Road
La Vergne, Tennessee 37086
Phone: 800-274-6848
www.jettools.com