



Operating Instructions and Parts Manual

Welding Positioner

Model WP-450



Baileigh Industrial
P.O. Box 531
Manitowoc, WI 54221-0531
Ph.: 920-684-4990
Fax: 920-684-3944
Baileigh-Sales@jpwindustries.com

BA9-1008396
Edition 3 07/2025
Copyright © 2020 Baileigh Industrial

1.0 Table of Contents

Section	Page
1.0 Table of Contents	2
2.0 Safety Instructions	3
3.0 About This Manual	5
4.0 Product Identification	6
5.0 Specifications	7
5.1 Overall Dimensions	8
6.0 Setup and Assembly	9
6.1 Unpacking and Checking Contents	9
6.2 Cleanup	9
6.3 Transporting and Lifting	9
6.4 Installation	10
6.5 Assembly	10
7.0 Electrical Connections	10
7.1 Power Specifications	10
7.2 Considerations	11
7.3 Extension Cord Safety	11
7.4 Power Cord Connection	11
8.0 Operation	11
8.1 Manual Mode	11
8.2 Auto Mode	12
9.0 Material Selection	12
10.0 Maintenance	12
11.0 Troubleshooting	14
12.0 Replacement Parts	15
12.1.1 Welding Positioner Assembly – Exploded View	15
12.1.2 Welding Positioner Assembly – Parts List	16
13.0 Wiring Diagram	17
14.0 Warranty and Service	18



2.0 Safety Instructions

⚠ WARNING

To reduce risk of injury:

1. FOR YOUR OWN SAFETY, READ INSTRUCTION MANUAL BEFORE OPERATING THE MACHINE. Learn the machine's application and limitations as well as the specific hazards.
2. Only trained and qualified personnel can operate this machine.
3. Make sure guards are in place and in proper working order before operating machinery.
4. Remove any adjusting tools. Before operating the machine, make sure any adjusting tools have been removed.
5. Keep work area clean. Cluttered areas invite injuries.
6. Overloading machine. By overloading the machine, you may cause injury from flying parts. DO NOT exceed the specified machine capacities.
7. Dressing material edges. Always chamfer and deburr all sharp edges.
8. Do not force tool. Your machine will do a better and safer job if used as intended. DO NOT use inappropriate attachments in an attempt to exceed the machine's rated capacity.
9. Use the right tool for the job. DO NOT attempt to force a small tool or attachment to do the work of a large industrial tool. DO NOT use a tool for a purpose for which it was not intended.
10. Dress appropriately. DO NOT wear loose fitting clothing or jewelry as they can be caught in moving machine parts. Protective clothing and steel toe shoes are recommended when using machinery. Wear a restrictive hair covering to contain long hair.
11. Use eye protection. Always wear ISO approved protective eye wear when operating machinery. Wear a full-face shield if you are producing metal filings. Eye wear shall be impact resistant, protective safety glasses with side shields which comply with ANSI Z87.1 specification. Use of eye wear which does not comply with ANSI Z87.1 specification could result in severe injury from breakage of eye protection.
12. Do not overreach. Maintain proper footing and balance at all times. DO NOT reach over or across a running machine.
13. Stay alert. Watch what you are doing and use common sense. DO NOT operate any tool or machine when you are tired.
14. Check for damaged parts. Before using any tool or machine, carefully check any part that appears damaged. Check for alignment and binding of moving parts that may affect proper machine operation.
15. Observe work area conditions. DO NOT use machines or power tools in damp or wet locations. Do not expose to rain. Keep work area well lighted. DO NOT use electrically powered tools in the presence of flammable gases or liquids.
16. Keep children away. Children must never be allowed in the work area. DO NOT let them handle machines, tools, or extension cords.
17. Keep visitors a safe distance from the work area.
18. Store idle equipment. When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep them out of reach of children.
19. DO NOT operate machine if under the influence of alcohol or drugs. Read warning labels on prescriptions. If there is any doubt, DO NOT operate the machine.
20. Sparks and hot material from welding can easily go through small cracks and openings into adjacent areas.
21. Do not weld where the atmosphere might contain flammable dust, gas, or liquid vapors such as from gasoline.
22. Wear oil-free protective garments such as leather gloves, heavy shirt, high shoes or boots, cuffless trousers, and a cap.
23. Watch for fire and keep a fire extinguisher close by.
24. DO NOT touch live electrical components or parts.
25. Turn off power before checking, cleaning, or replacing any parts.
26. Be sure all equipment is properly installed and grounded according to national, state, and local codes.
27. Keep all cords dry, free from grease and oil, and protected from sparks and hot metal.
28. Inspect power and control cables periodically. Replace if damaged or bare wires are exposed. Bare wiring can kill!
29. Keep visitors a safe distance from the work area.

Familiarize yourself with the following safety notices used in this manual:



This means that if precautions are not heeded, it may result in minor injury and/or machine damage.



This means that if precautions are not heeded, it may result in serious or fatal, injury.

Save the Instructions

3.0 About This Manual

This manual is provided by Baileigh Industrial, covering the safe operation and maintenance procedures for a Baileigh Model WP-450 Welding Positioner. This manual contains instructions on installation, safety precautions, general operating procedures, maintenance instructions and parts breakdown. Your machine has been designed and constructed to provide consistent, long-term operation if used in accordance with the instructions as set forth in this document.

Technical Support handles questions on setup, operation, schematics, warranty issues, and individual parts needed. Our Technical Support department can be reached at 920-684-4990.

If there are questions or comments, please contact your local supplier or Baileigh Industrial. We can also be reached at our web site: www.baileigh.com.

Retain this manual for future reference. If the machine transfers ownership, the manual should accompany it.

WARNING

Read and understand the entire contents of this manual before attempting assembly or operation! Failure to comply may cause serious injury!

Register your product online -

<https://baileigh.com/product-registration>



4.0 Product Identification




Table 4-1

Item	Part Name	Description
A	Foot Switch	Controls starting and stopping of table rotation
B	Electrical Cabinet	Houses the electrical operating components.
C	DC Drive Motor	Provides power to rotate the table
D	Table	Supports and secure piece part for welding. Rotates when activated by the operator.

Item	Part Name	Description
E	Table Rotate Gearbox	Used to support and rotate the table
F	Tilt Lock Handle	Loosens to allow the table to tilt from horizontal to vertical or positions in between. Lock the handle to hold the tilted position.
G	Carbon Contact Brush	Connect the welding ground cable to the carbon contact brush cable to provide the ground path to the table and thus the piece part during welding.
H	Fuse Holder	Holds 10A power fuse
J	Power Indicator Light	Lights RED when power switch is turned on
K	TEST/WELD Switch	2-position toggle switch
L	Power ON/OFF Switch	2-position toggle power switch
M	Speed Adjust Knob	Turning clockwise (cw) increases the rotation speed
N	FOR/STOP/REV. Switch	Used to change direction of table
O	AUTO/MAN. Switch	Changes mode of footswitch from auto to manual

5.0 Specifications

Table 5-1

Model number	WP-450
Stock number	BA9-1008396
Motor and Electrical	
Motor	DC90V, 65W, 1800RPM
Input Power	110V, 60Hz, 10A
General Specifications	
Load Capacity – Table Horizontal (0°)	485lbs (220kg)
Load Capacity – Table Tilted (0° - 90°)	Up to 390lbs (177kg) Center of balance 6" from table
Speed	4RPM
Disc OD / ID	13" (330mm) / 1.34" (34mm)
Table Tilt Degrees	0° and 90° (from horizontal)
T-Slots	3 Slots
Drive	Foot Pedal, Automatic/Manual
Weights and Dimensions	
Weight	100lbs (45kg)
Table Height in Flat Position	16.50" (419mm)

- Solid State D.C. variable speed table rotation.
- Heavy duty fully enclosed worm gear rotation drive.
- On/off electric foot control.
- 120-volt AC 60 Hz input power.
- Machined table with centering grooves and 3 slots for nuts.
- Power on indicator light.
- Clockwise and counterclockwise table rotation.
- Test/Weld switch (To be connected by customer's electrician)

5.1 Overall Dimensions




Figure 5-1

IMPORTANT: The weld positioner must be anchored to a sturdy worktable or bench that is capable of supporting the full weight of the machine and the work material and prevent the machine and work material from tipping.

⚠ WARNING

Read and understand the entire contents of this manual before attempting assembly or operation. Failure to comply may cause serious injury.

6.0 Setup and Assembly

6.1 Unpacking and Checking Contents

⚠ WARNING

SUFFOCATION HAZARD! Immediately discard any plastic bags and packing materials to eliminate choking and suffocation hazards to children and animals.

⚠ WARNING

If any parts are missing, **DO NOT** place the machine into service until the missing parts are obtained and installed correctly.

Your Baileigh machine is shipped complete. Separate all parts from the packing material and check each item carefully. Make certain all items are accounted for before discarding any packing material.

6.2 Cleanup

⚠ WARNING

DO NOT USE gasoline or other petroleum products to clean the machine. They have low flash points and can explode or cause fire.

⚠ CAUTION

When using cleaning solvents work in a well-ventilated area. Many cleaning solvents are toxic if inhaled.

Your machine may be shipped with a rustproof waxy coating and/or grease on the exposed unpainted metal surfaces. Fully and completely remove this protective coating using a degreaser or solvent cleaner. Moving items will need to be moved along their travel path to allow for cleaning the entire surface. For a more thorough cleaning, some parts will occasionally have to be removed. **DO NOT USE** acetone or brake cleaner as they may damage painted surfaces.

Follow manufacturer's label instructions when using any type of cleaning product. After cleaning, wipe unpainted metal surfaces with a light coating of quality oil or grease for protection.

IMPORTANT: This waxy coating is **NOT** a lubricant and will cause the machine to stick and lose performance as the coating continues to dry.

6.3 Transporting and Lifting

NOTICE

Lifting and carrying operations should be carried out by skilled workers, such as a truck operator, crane operator, etc. If a crane is used to lift the machine, attach the lifting chain carefully, making sure the machine is well balanced.

Follow these guidelines when lifting with truck or trolley:

- The lift truck must be able to lift at least 1.5 – 2 times the machines gross weight.
- Make sure the machine is balanced. While transporting, avoid rough or jerky motion, and maintain a safe clearance zone around the transport area.
- Use a forklift with sufficient lifting capacity and forks that are long enough to reach the complete width of the machine.
- Remove the securing bolts that attach the machine to the pallet.
- Approaching the machine from the side, lift the machine on the frame taking care that there are no cables or pipes in the area of the forks.
- Move the machine to the required position and lower gently to the floor.
- Level the machine so that all the supporting feet are taking the weight of the machine, and no rocking is taking place.




Figure 6-1

Follow these guidelines when lifting crane or hoist:

- Always lift and carry the machine with the lifting holes provided at the top of the machine.
- Use lift equipment such as straps, chains, capable of lifting 1.5 to 2 times the weight of the machine.
- Take proper precautions for handling and lifting.
- Check if the load is properly balanced by lifting it an inch or two.

- Lift the machine, avoiding sudden accelerations or quick changes of direction.
- Locate the machine where it is to be installed, and lower slowly until it touches the floor.

6.4 Installation

IMPORTANT:

Consider the following when looking for a suitable location to place the machine:

- Overall weight of the machine.
- Weight of material being processed.
- Sizes of material to be processed through the machine.
- Space needed for auxiliary stands, worktables, or other machinery.
- Clearance from walls and other obstacles.
- Maintain an adequate working area around the machine for safety.
- Have the work area well illuminated with proper lighting.
- Keep the floor free of oil and make sure it is not slippery.
- Remove scrap and waste materials regularly, and make sure the work area is free from obstructing objects.
- If long lengths of material are to be fed into the machine, make sure that they will not extend into any aisles.

IMPORTANT: The weld positioner must be anchored to a sturdy worktable or bench that is capable of supporting the full weight of the machine and the work material and prevent the machine and work material from tipping.

Before beginning assembly, take note of the following precautions and suggestions.

- Is the machine is bolted to the pallet? Before attempting any of the assembly procedures remove all of the loose parts and hardware and unbolt the machine from the pallet.
- **LEVELING:** The machine should be sited on a level, concrete floor. Provisions for securing it should be in position prior to placing the machine. The accuracy of any machine depends on the precise placement of it to the mounting surface.
- **FLOOR:** This tool distributes a large amount of weight over a small area. Make certain that the floor is capable of supporting the weight of the machine, work stock, and the operator. The floor should also be a level surface. If the unit wobbles or rocks once in place, be sure to eliminate by using shims.
- **WORKING CLEARANCES:** Take into consideration the size of the material to be processed. Make sure that you allow enough space for you to operate the machine freely.

- **POWER SUPPLY PLACEMENT:** The power supply should be located close enough to the machine so that the power cord is not in an area where it would cause a tripping hazard. Be sure to observe all electrical codes if installing new circuits and/or outlets.

6.5 Assembly

WARNING

For your own safety, DO NOT connect the machine to the power source until the machine is completely assembled and you read and understand the entire instruction manual.

The Baileigh WP-450 can be floor or bench mounted. When mounting the weld positioner on a bench, make sure it is adequately secured to avoid any possibility of tipping over with a load.

When loading the piece part onto the worktable, follow these guidelines to avoid overturning the positioner or overloading the gear train and motor.

- Calculate the total weight of the piece part including all fixturing.
Note: The WP-450 has a load capacity of 485 lbs. (220 kg).
- Locate the center of gravity of the piece part with all fixturing attached to the table.
- Double check that all fixturing is securely attached to the table.

7.0 Electrical Connections

CAUTION

HAVE ELECTRICAL UTILITIES CONNECTED TO MACHINE BY A CERTIFIED ELECTRICIAN!

CAUTION

Check if the available power supply is the same as listed on the machine nameplate.

WARNING

Make sure the grounding wire (green) is properly connected to avoid electric shock. DO NOT switch the position of the green grounding wire if any electrical plug wires are switched during hookup.

7.1 Power Specifications

Your machine is wired for 110 volts, 60hz alternating current. Before connecting the machine to the power source, make sure the power source is OFF.

Before switching on the power, you must check the voltage and frequency of the power to see if they meet with the requirement, the allowed range for the voltage is $\pm 5\%$, and for the frequency is $\pm 1\%$.

7.2 Considerations

- Observe local electrical codes when connecting the machine.
- The circuit should be protected with a time delay fuse or circuit breaker with an amperage rating slightly higher than the full load current of machine.
- A separate electrical circuit should be used for your machines. Before connecting the motor to the power line, make sure the switch is in the "OFF" position and be sure that the electric current is of the same characteristics as indicated on the machine.
- All line connections should make good contact. Running on low voltage will damage the motor.
- In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This machine is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING

In all cases, make certain the receptacle in question is properly grounded. If you are not sure, have a qualified electrician check the receptacle.

- Improper connection of the equipment-grounding conductor can result in risk of electric shock. The conductor with insulation having an outer surface that is green with or without yellow stripes is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.
- Check with qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the machine is properly grounded.
- Repair or replace damaged or worn cord immediately.

7.3 Extension Cord Safety

The Extension cord should be in good condition and meet the minimum wire gauge requirements listed below:

Table 7-1

Amp Rating	Length		
	25ft	50ft	100ft
1-12	16	16	14
13-16	14	12	12
17-20	12	12	10
21-30	10	10	No
Wire Gauge			

An undersized cord decreases line voltage, causing loss of power and overheating. All cords should use a ground wire and plug pin. Replace any damaged cords immediately.

7.4 Power Cord Connection

1. Turn the main switch on the control panel to the OFF position.
2. Unwrap the power cord and route the cord away from the machine toward the power supply.
 - a. Route the power cord so that it will NOT become entangled in the machine in any way.
 - b. Route the cord to the power supply in a way that does NOT create a trip hazard.
3. Connect the power cord to the power supply and check that the power cord has not been damaged during installation.
4. When the machine is clear of any obstruction. The main power switch may be turned ON to test the operation.
5. Turn the switch OFF when the machine is not in operation.

8.0 Operation

CAUTION

Always wear proper eye protection with side shields, safety footwear, and leather gloves to protect from burrs, sharp edges and HOT Parts.

8.1 Manual Mode

1. Set the AUTO. MANU. Toggle switch to MANUAL.
2. To have table movement, select either forward or reverse. The speed adjustment knob must be set to a value above 10 to see movement.
3. Press down and hold the foot switch. The table will continue rotating as long as the foot switch is depressed. When you let your foot off the foot switch, the table will stop turning.



Figure 8-1

8.2 Auto Mode

1. Set the AUTO. MANU. Toggle switch to AUTO.
2. Press down and release the foot switch. The table will continue rotating at the preset speed.
3. To stop the table from rotating, again press and release the foot switch.

⚠ CAUTION

Switching rotation direction before coming to a complete stop may damage motor and/or gearbox.

The power indicator will light **RED** when the toggle switch is turned to the **ON** position.



Figure 8-2

The TEST/WELD toggle turns the circuit on and off that controls your welding power unit.

The power unit connects to the terminal block as indicated by the arrow.




Figure 8-3

9.0 Material Selection

⚠ CAUTION

It must be determined by the customer that materials being processed through the machine are **NOT** potentially hazardous to operator or personnel working nearby.

10.0 Maintenance

⚠ WARNING

Make sure the electrical disconnect is **OFF** before working on the machine.

⚠ WARNING

Maintenance should be performed on a regular basis by qualified personnel.

⚠ WARNING

Always follow proper safety precautions when working on or around any machinery.

- Check daily for any unsafe conditions and fix immediately.
- Check that all nuts and bolts are properly tightened.
- On a weekly basis clean the machine and the area around it.
- Lubricate gear teeth and rotating devices.
- Apply rust inhibitive lubricant to all non-painted surfaces.
- Check oil level in gear cases and fill if necessary.
- Inspect foot pedal for proper operation.

- Check for any broken wires, loose connections, or worn parts.

Note: Proper maintenance can increase the life expectancy of your machine.

11.0 Troubleshooting


WARNING

Make sure the electrical disconnect is OFF before working on the machine.

Fault	Probable Cause	Remedy
Motor does not start	No power.	Check power supply for 110V, 60Hz.
	Blown fuse.	Check and replace fuse.
	Motor burned out.	Replace motor.
Indicator light not lit	Light burned out	Replace indicator light.
	Blown fuse.	Check and replace fuse.
	No power.	Check power supply for 110V, 60Hz.
Table fails to turn	Faulty foot switch.	Check and replace foot switch.
	Toggle switch in STOP position.	Select either FOR. or REV.
	Speed adjustment knob set to zero.	Increase setting to 10 or more to see movement.
	Motor burned out.	Replace motor.
	Faulty circuit board	Replace circuit board.

12.0 Replacement Parts

12.1.1 Welding Positioner Assembly – Exploded View




12.1.2 Welding Positioner Assembly – Parts List

Index No	Part No	Description	Size	Qty
1	BA9-5155	Left Plate		1
2	**	Right Plate		1
3	BA1-5151	Hexagonal Rod		3
5	BA1-2501	Fixed Axis Shaft		1
6	BA1-5154	Shaft Fixed Block w/Shaft		1
7	BA1-5150	Bearing SBPF-204		2
8	BA9-1232274	Handle		1
9	**	Turbo Gear – 60-1/15		1
10	**	Control Box H-Type		1
	BA9-1020965	On/Off Switch (not shown)		1
	BA9-1017075	EMC Filter (not shown)		1
	BA9-1012192	Motor and Gear Box (not shown)		1

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

13.0 Wiring Diagram



14.0 Warranty and Service

Thank you for your purchase of a machine from Baileigh Industrial. We hope that you find it productive and useful to you for a long time to come.

Inspection & Acceptance. Buyer shall inspect all Goods within ten (10) days after receipt thereof. Buyer's payment shall constitute final acceptance of the Goods and shall act as a waiver of the Buyer's rights to inspect or reject the Goods unless otherwise agreed. If Buyer rejects any merchandise, Buyer must first obtain a Returned Goods Authorization ("RGA") number before returning any Goods to Seller. Goods returned without an RGA will be refused. Seller will not be responsible for any freight costs, damages to Goods, or any other costs or liabilities pertaining to Goods returned without an RGA. Seller shall have the right to substitute a conforming tender. Buyer will be responsible for all freight costs to and from Buyer and repackaging costs, if any, if Buyer refuses to accept shipment. If Goods are returned in unsalable condition, Buyer shall be responsible for full value of the Goods. Buyer may not return any special-order Goods. Any Goods returned hereunder shall be subject to a restocking fee equal to 30% of the invoice price.

Specifications. Seller may, at its option, make changes in the designs, **specifications**, or components of the Goods to improve the safety of such Goods, or if in Seller's judgment, such changes will be beneficial to their operation or use. Buyer may not make any changes in the specifications for the Goods unless Seller approves of such changes in writing, in which event Seller may impose additional charges to implement such changes.

Limited Warranty. Seller warrants to the original end-user that the Goods manufactured or provided by Seller under this Agreement shall be free of defects in material or workmanship for a period of twelve (12) months from the date of purchase, provided that the Goods are installed, used, and maintained in accordance with any instruction manual or technical guidelines provided by the Seller or supplied with the Goods, if applicable. The original end-user must give written notice to Seller of any suspected defect in the Goods prior to the expiration of the warranty period. The original end-user must also obtain an RGA from Seller prior to returning any Goods to Seller for warranty service under this paragraph. Seller will not accept any responsibility for Goods returned without an RGA. The original end-user shall be responsible for all costs and expenses associated with returning the Goods to Seller for warranty service. In the event of a defect, Seller, at its sole option, shall repair or replace the defective Goods or refund to the original end-user the purchase price for such defective Goods. Goods are not eligible for replacement or return after a period of 10 days from date of receipt. The foregoing warranty is Seller's sole obligation, and the original end-user's exclusive remedy, with regard to any defective Goods. This limited warranty does not apply to: (a) die sets, tooling, and saw blades; (b) periodic or routine maintenance and setup, (c) repair or replacement of the Goods due to normal wear and tear, (d) defects or damage to the Goods resulting from misuse, abuse, neglect, or accidents, (f) defects or damage to the Goods resulting from improper or unauthorized alterations, modifications, or changes; and (f) any Goods that has not been installed and/or maintained in accordance with the instruction manual or technical guidelines provided by Seller.

EXCLUSION OF OTHER WARRANTIES. THE FOREGOING LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ANY AND ALL OTHER EXPRESS, STATUTORY, OR IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED. NO WARRANTY IS MADE WHICH EXTENDS BEYOND THAT WHICH IS EXPRESSLY CONTAINED HEREIN.

Limitation of Liability. IN NO EVENT SHALL SELLER BE LIABLE TO BUYER OR ANY OTHER PARTY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR DOWN TIME) ARISING FROM OR IN MANNER CONNECTED WITH THE GOODS, ANY BREACH BY SELLER OR ITS AGENTS OF THIS AGREEMENT, OR ANY OTHER CAUSE WHATSOEVER, WHETHER BASED ON CONTRACT, TORT OR ANY OTHER THEORY OF LIABILITY. BUYER'S REMEDY WITH RESPECT TO ANY CLAIM ARISING UNDER THIS AGREEMENT IS STRICTLY LIMITED TO NO MORE THAN THE AMOUNT PAID BY THE BUYER FOR THE GOODS.

Force Majeure. Seller shall not be responsible for any delay in the delivery of, or failure to deliver, Goods due to causes beyond Seller's reasonable control including, without limitation, acts of God, acts of war or terrorism, enemy actions, hostilities, strikes, labor difficulties, embargoes, non-delivery or late delivery of materials, parts and equipment or transportation delays not caused by the fault of Seller, delays caused by civil authorities, governmental regulations or orders, fire, lightning, natural disasters or any other cause beyond Seller's reasonable control. In the event of any such delay, performance will be postponed by such length of time as may be reasonably necessary to compensate for the delay.

Installation. If Buyer purchases any Goods that require installation, Buyer shall, at its expense, make all arrangements and connections necessary to install and operate the Goods. Buyer shall install the Goods in accordance with any Seller instructions and shall indemnify Seller against any and all damages, demands, suits, causes of action, claims and expenses (including actual attorneys' fees and costs) arising directly or indirectly out of Buyer's failure to properly install the Goods.

Work By Others; Safety Devices. Unless agreed to in writing by Seller, Seller has no responsibility for labor or work performed by Buyer or others, of any nature, relating to design, manufacture, fabrication, use, installation, or provision of Goods. Buyer is solely responsible for furnishing and requiring its employees and customers to use all safety devices, guards and safe operating procedures required by law and/or as set forth in manuals and instruction sheets furnished by Seller. Buyer is responsible for consulting all operator manuals, ANSI or comparable safety standards, OSHA regulations and other sources of safety standards and regulations applicable to the use and operation of the Goods.

Remedies. Each of the rights and remedies of Seller under this Agreement is cumulative and in addition to any other or further remedies provided under this Agreement or at law or equity.

Attorney's Fees. In the event legal action is necessary to recover monies due from Buyer or to enforce any provision of this Agreement, Buyer shall be liable to Seller for all costs and expenses associated therewith, including Seller's actual attorney fees and costs.

Governing Law/Venue. This Agreement shall be construed and governed under the laws of the State of Wisconsin, without application of conflict of law principles. Each party agrees that all actions or proceedings arising out of or in connection with this Agreement shall be commenced, tried, and litigated only in the state courts sitting in Manitowoc County, Wisconsin or the U.S. Federal Court for the Eastern District of Wisconsin. Each party waives any right it may have to assert the doctrine of "forum non conveniens" or to object to venue to the extent that any proceeding is brought in accordance with this section. Each party consents to and waives any objection to the exercise of personal jurisdiction over it by courts described in this section. Each party waives to the fullest extent permitted by applicable law the right to a trial by jury.

Summary of Return Policy:

- 10 Day acceptance period from date of delivery. Damage claims and order discrepancies will not be accepted after this time.
- You must obtain a Baileigh Industrial issued RGA number PRIOR to returning any materials.
- Returned materials must be received at Baileigh Industrial in new condition and in original packaging.
- Altered items are not eligible for return.
- Buyer is responsible for all shipping charges.
- A 30% re-stocking fee applies to all returns.

Baileigh Industrial makes every effort to ensure that our posted specifications, images, pricing, and product availability are as correct and timely as possible. We apologize for any discrepancies that may occur. Baileigh Industrial reserves the right to make any and all changes deemed necessary in the course of business including but not limited to pricing, product specifications, quantities, and product availability.

For Customer Service & Technical Support:

Please contact one of our knowledgeable Sales and Service team members at:
(920) 684-4990 or e-mail us at Baileigh-Service@jpwindustries.com



BAILEIGH INDUSTRIAL

1625 DUFEEK DRIVE MANITOWOC, WI 54220

PHONE: 920.684.4990 FAX: 920.684.3944

www.baileigh.com